

MANUAL

For Installation, Maintenance and Operation

IMA Series Actuators



| Original instructions in English. Translations in community languages supplied as required. |
|---|
| Information furnished is believed to be accurate and reliable. However, Tolomatic assumes no responsibility for its use or for any errors that may appear in this document. |
| Tolomatic reserves the right to change the design or operation of the equipment described herein and any associated motion products without notice. Information in this document is subject to change without notice. |
| |
| |
| |

CONTENTS

| CONTENTS | 3 |
|---|------------|
| LIST OF FIGURES & TABLES | 5 |
| 1: SAFETY | |
| 1.0 SAFETY 1.1 SAFETY SYMBOLS 1.2 SAFETY CONSIDERATIONS | 7 7 |
| 2: IMA PRODUCT OVERVIEW | 10 |
| 2.0 GENERAL DESCRIPTION. 2.1 PRODUCT FEATURES. 2.2 INSTALLATION. 2.3 CABLE ROUTING. 2.4 ACTUATOR ORIENTATION. 2.5 EMC WIRING GUIDELINES. 2.6 MOTION CONTROL SYSTEM SELECTION RECOMMENDATIONS. | 1011111112 |
| 2.7 IDENTIFICATION LABEL 2.5 CERTIFICATION 2.6 MANUFACTURER | 12 |
| 3: IMA ACTUATOR PRODUCT CONFIGURATION | 13 |
| 3.1 Tolomatic IMA Actuator Series Configuration 3.2 Standard Configurations and options 3.2.1 Screw Selection 3.2.2 Motor Voltage 3.2.3 Internal Holding Brake Option 3.2.4 Standard Mounting Options 3.2.5 Mounting Options 3.2.6 Standard Rod End 3.2.7 Rod End Options 3.2.8 Other Options 3.2.9 Special Options 3.2.10 Feedback Device 3.2.11 Cable & Connector(s) 3.2.12 Servo Drive 3.2.13 Rockwell Automation PartnerNetwork™ Program. | |
| 4.1 TOLOMATIC IMA ACTUATOR SYSTEM CONFIGURATION 4.2 GENERAL OPERATION 4.3 COLD TEMPERATURE STARTUP PROCEDURE 4.4 PLANNING YOUR INSTALLATION 4.4.1 ALIGNMENT 4.4.2 SIDE LOAD CONSIDERATIONS 4.5 MECHANICAL INSTALLATION INSTRUCTIONS 4.6 MOUNTING 4.5 FIELD INSTALLATION OF ARO (ANTI ROTATION) OPTION | |
| 5: ELECTRICAL INSTALLATION | |
| 5.1 CONNECTOR ORIENTATION | 25 |

| 5.2 FEEDBACK INFORMATION | 25 |
|--|----|
| 5.3 FEEDBACK COMMUTATION | 26 |
| 5.4 FEEDBACK COMMUTATION DETAILS | 26 |
| 5.5 FEEDBACK SPECIFICATIONS | |
| 5.6 THERMAL SENSOR SPECIFICATIONS | |
| 5.7 Connector Pinouts | |
| 5.7.1 TOLOMATIC STANDARD - DT1 | |
| 5.7.2 ALLEN BRADLEY MP MOTOR SERIES - DA1 | |
| 5.7.3 ALLEN BRADLEY VP MOTOR SERIES - DA2 | |
| 5.7.4 BOSCH REXROTH MSK MOTOR SERIES - DB1 | |
| 5.7.5 CONTROL TECHNIQUES FM MOTOR SERIES - DE1 | |
| 5.7.6 CONTROL TECHNIQUES NT MOTOR SERIES - DE2 | |
| 5.7.7 LENZE MCS MOTOR SERIES - DL1 | |
| 5.7.8 SIEMENS 1F MOTOR SERIES - DS1 | |
| 6: IMA OPERATION AND START UP CONSIDERATIONS | 45 |
| 6.1 ATTACHING CABLES & HOMING / MECHANICAL TRAVEL LIMITS | 45 |
| • 6.2 Brake | 45 |
| 7: IMA REPAIR AND MAINTENANCE | 47 |
| 7.1 LUBRICATION | |
| 7.2 Periodic Maintenance | |
| 7.3 PROCEDURE FOR LUBRICATION | |
| 7.4 TOLOMATIC IMA MAINTENANCE AND REPAIR | |
| 7.5 STORAGE RECOMMENDATIONS | |
| APPENDIX A: SPECIFICATIONS | |
| A.1 ACTUATOR SPECIFICATIONS | |
| A.2 MOTOR SPECIFICATIONS: | |
| A.3 Brake Specifications | |
| A.4 SPEED VS THRUST GRAPHS | |
| A.5 CALCULATING RMS THRUST AND VELOCITY FOR CONTINUOUS DUTY: | |
| A.6 CRITICAL SPEED | |
| A.7 BALL & ROLLER SCREW LIFE | |
| A.8 STANDARD THERMAL SWITCH SPECIFICATIONS | |
| APPENDIX B: TROUBLESHOOTING PROCEDURE | |
| APPENDIX C: WARRANTY | 56 |
| C.1 Warranty | 56 |
| APPENDIX D: DECLARATION OF CONFORMITY | 58 |

LIST OF FIGURES & TABLES

| Figure 1.1: Do not carry IMA by connectors or cables. | 9 |
|---|-----|
| Figure 2.1: Tolomatic IMA Actuator | 10 |
| Figure 2.2: IMA major components | 10 |
| Figure 2.3: Recommended routing of Tolomatic IMA Actuator cabling. | 11 |
| Figure 2.4: 1. & 2. Recommended IMA thrust rod orientation is down or horizontal. 3. Due to increased risk of contamina and ingress never orient the IMA actuator with the thrust rod up. | |
| Figure 2.2: Tolomatic IMA Actuator identification label. | 12 |
| Figure 3.1: Tolomatic IMA Actuator ordering codes and descriptions | 14 |
| Figure 3.2: Standard mounting for the IMA is four (4) threaded holes on the front face (rod end) of the actuator | 15 |
| Figure 3.3: Optional mounting for the Tolomatic IMA Actuator | 15 |
| Figure 3.4: Standard rod end for the IMA is internal threads | 15 |
| Figure 3.5: Rod End Options for the Tolomatic IMA Actuator | 16 |
| Figure 3.5: Rod End Options for the Tolomatic IMA Actuator | 16 |
| Figure 4.1: Typical connections for a single-axis system with an Tolomatic IMA Actuator with optional brake to a RSW serve system drive | |
| Figure 4.2: Side load must not exceed maximum values represented by the lines in the graph | 20 |
| Figure 4.3: Do not carry IMA by connectors or cables. | 21 |
| Figure 4.4: Use straps and winch to position heavy IMA actuator | 21 |
| Figure 4.5: Hold thrust rod stationary using a wrench on the flats of the rod end when attaching accessories, linkages or loa the actuator. Two wrenches are used here: The crescent wrench prevents the thrust rod from rotating, the torque wrench w fasten the spherical rod eye option to the actuator rod end. Torque values provided in Table 4.1 | ill |
| Table 4.1: Rod end torque recommendations | |
| Table 4.2: Tapped hole torque recommendations | |
| Table 4.3: Mounting Plate (MP2) Clearance Hole Bolt and Torque Requirements (Minimum Fastener Grade 8.8) | 23 |
| Table 4.4: Front Flange Mount (FFG) Clearance Hole Bolt and Torque Requirements (Minimum Fastener Grade 8.8) | 23 |
| Figure 4.6: View of ARO (Anti Rotate Option) | |
| Figure 5.3: Connector rotation. Note that the Tolomatic standard connectors may be rotated from -90° to +180° allowing for cables to connect toward the front (rod end, as manufactured), to either side, both sides, or back of actuator | r |
| Figure 5.4: Drawing of box mount connectors used on some Tolomatic IMA Actuators. | |

| Figure 5.5: Thrust rod movement relative to motor rotation | 26 |
|---|----|
| Figure 5.6: Back EMF Voltage vs Electrical Angle | 27 |
| Figure 5.7: Back EMF Voltage Phase to Phase vs Electrical Angle | 27 |
| Figure 5.8: Hall Alignment | 28 |
| Figure 5.9: Motor rotational position at 0 | 28 |
| Figure 5.10: Motor rotational position at 90 | 29 |
| Figure 6.1: Fastest Engage / Disengage time, least protection | 45 |
| Figure 6.2: Increased Engage / Disengage time, best protection | 46 |
| Figure 7.1: Roller Screw Lubrication Interval Graph | 48 |
| Figure 7.1: A standard grease zerk allows periodic relubrication for Tolomatic IMA Actuators. This can be done without removing the actuator from its installation. | 50 |

1: SAFETY

1.0 Safety

1.1 Safety Symbols

General

Read completely through the applicable sections of the manual before the equipment/unit is unpacked, installed or operated. Pay careful attention to all of the dangers, warnings, cautions and notes stated in the manual. Serious injury to persons or damage to the equipment may result if the information in the manual is not followed.

Safety Symbols

Items that are specifically marked DANGER, WARNING, CAUTION, PROHIBITIVE, MANDATORY ACTION, or NOTE! are arranged in a hierarchical system and have the following meaning:

▲ DANGER

Indicates a very hazardous situation which, if not avoided, could result in death or serious injury. This signal word is limited to the most extreme situations.

△WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

A CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in property damage, minor or moderate injury.



Indicates Prohibited Action



Indicates Mandatory Action



Information that requires special attention is stated here.



WARNING! Normal operating temperature of weld actuator can range from 135 degrees F (57°C) to 175 degrees F (79°C).

1.2 Safety Considerations

Proper and Safe Use of Product

Fail Safe e-Stop Recommendations

A means for a fail safe e-stop is highly recommended to ensure equipment and personal safety. The e-stop should provide a means to remove main power from the actuator to cease and prevent any unwanted motion.

Device Damage Prevention

To prevent permanent damage to the device, proper care should be taken not to exceed published voltage, current, temperature, and load/force ratings. In addition, proper mechanical assembly and proper wiring should be verified and safety measures checked before applying power to the complete equipment package.

The only field maintenance that may be performed on the IMA include lubrication and replacement of the rod wiper. All other repair or maintenance for the IMA must be performed at Tolomatic.

Personal Safety

During normal operation the actuator can become hot, especially the motor housing. It is highly recommended to display proper safety notices and implement proper safety measures to prevent contact with hot surfaces. In addition, the case ground should be tied to an earth ground to prevent the presence of case voltage. During normal operation, the actuator rod travels in and out creating a possible pinch point.

Proper guarding and signage must be used prevent entry into possible pinch zones and contact with hot surfaces. It is highly recommended to display proper safety notices and implement proper safety measures to prevent

contact with hot surfaces. Handling and Unpacking

When unpacking and handling the actuator, care should be taken not to drop the actuator as this can damage the connectors, internal electronics, or cause misalignment of the actuator feedback device. Damage the internal mechanical components may cause poor performance or render the actuator non-functional. Since this is an electromechanical device, proper ESD measures should be taken to avoid static electricity from contacting the signal and power lines of the device. As this can damage the internal mechanical components rendering the actuator damaged or non-functional.

Packing and Transport



Package actuator to prevent damage during transport. It is recommended that the actuator be returned in its original packaging. If the original packaging is not available, then follow these recommendations.

- 1. Foam in place if possible.
- 2. Reinforce ends of box with multiple layers of cardboard or wood to prevent the actuator from breaking through the packaging during shipment.
- 3. Support the connectors or cables so that enough packaging or foam is in place to prevent shipping damage.
- 4. It is best to ship one unit per container because individual items that are not isolated with stable packaging (foam in place) from each other often get damaged during shipment.
- 5. When shipping more than one unit in a single container, it is recommended to foam in place to prevent damage during shipping to both the units and the packaging.
- 6. Add the RMA on the outside of the packaging. Failure to do so will delay processing.

Tolomatic Last Revision: 2/4/2022

A CAUTION





Figure 1.1: Do not carry IMA by connectors or cables.

The Tolomatic IMA Actuator weight range is approximately 3.0 to 42 kg (6.6 to 93 lb). Special care must be taken when lifting this device. Do not carry by the connectors or cables. The connectors are not rated to support the weight of the actuator.

Modifications to the Equipment

△WARNING

The manufacturer takes no responsibility whatsoever if the equipment is modified or if the equipment is used in any way beyond performance specifications. Unauthorized modifications or changes to the equipment are strictly forbidden, and void all warranties.

Repair and Maintenance

△WARNING

All power and supply media must be shut OFF before any work is performed on any equipment that is associated with the Tolomatic IMA Actuator. The only field maintenance that may be performed on the Tolomatic IMA Actuator is lubrication. All other repair or maintenance for the Tolomatic IMA Actuator must be performed at Tolomatic.

Requirement Regarding Personnel



All personnel must be completely informed regarding all safety regulations and the function of the equipment.

Risk Area and Personnel

When installed, pinch points are generated capable of high damaging forces. The risk area surrounding the Tolomatic IMA Actuator must either be enclosed or clearly marked, including display signage in accordance with all applicable national and international legal requirements. The risk area must be protected by a safety system that stops the equipment if anyone enters the risk area. Personnel who enter the risk area must be authorized, trained and qualified for the different tasks inside the risk area.

2: IMA PRODUCT OVERVIEW

2.0 General Description

Tolomatic IMA Actuators



Figure 2.1: Tolomatic IMA Actuator

The IMA is a compact, durable, high force rod-style actuator. The IMA integrates a servo motor into the mechanical design to minimize the overall envelope. The patented design allows for easy re-lubrication without disassembly for extremely long service life.

2.1 Product Features




Figure 2.2: IMA major components

2.2 Installation

The IMA is a compact high force screw drive servo actuator. The IMA provides linear motion of the moveable rod

developing the required thrust force and velocity in a variety of applications.

△WARNING

Before installation and commissioning of the equipment, this manual and all accompanying manufacturer documents and manuals MUST be completely read by the appropriate personnel. All warning texts must be given special attention.

2.3 Cable Routing

It is recommended that the power and signal cables for Tolomatic IMA Actuators be routed as far apart as possible to minimize electrical noise in communication cables.

Over time, liquid contaminants such as oil and cleaning solutions may accumulate on the cables and into the connectors if they are an exposed type. To minimize the introduction of contaminants to the connector, route the cables so that there is a loop in the cable just prior to its attachment to the connector.

Examples are shown depending on the orientation of the connectors. Units mounted in such a way that the connectors are on the bottom surface of the actuator require no looping.




Figure 2.3: Recommended routing of Tolomatic IMA Actuator cabling.



The standard cables from Tolomatic are not flex rated and have a minimum bend radius of 3.75 in (95mm). Any repeated flexing or excessive bending can result in broken conductors and intermittent faults.

2.4 Actuator Orientation

1. Rod End Down (Best) 2. Rod End Horizontal (Good) 3. Rod End Up (Never)
It is not recommended to mount the IMA with the thrust rod pointing upwards. Mounting the thrust rod vertically increases risk of contamination and ingress..




Figure 2.4: **1. & 2.** Recommended IMA thrust rod orientation is down or horizontal. **3.** Due to increased risk of contamination and ingress never orient the IMA actuator with the thrust rod up.

2.5 EMC Wiring Guidelines

Shielding and grounding

Tolomatic supplied cables have the proper shielding and are recommended for proper installation. If additional or alternate cables are require, braided shield cables are recommended. The standard cables provided by Tolomatic have an overall braided shield. To minimize EMI and ensure system reliability, all shield drain wires from all cables should be tied to a common earth ground. Also, make sure to follow the drive manufacturer's recommendations on proper cable dressing, shield and ground connections to ensure reliable operations. To minimize EMI and ensure system reliability, shield drain wires from all cables should be tied to a common earth ground.

△WARNING

Thrust rod is not electrically connected to ground. The thrust rod should be earth grounded during installation for safety when possible.

2.6 Motion Control System Selection Recommendations

It is recommended that all servo drives be selected based on the following important parameters:

- a) CE and UL approved system
- b) Thermal switch input
- c) Servo drive sizing key parameters for IMA-S
 - i) Peak current
 - ii) Voltage
 - iii) Peak RPM
 - iv) Max current switching frequency

2.7 Identification Label



Figure 2.2: Tolomatic IMA Actuator identification label.

Do not remove the identification label. Do not render it unreadable.

2.5 Certification







2.6 Manufacturer

Tolomatic, Inc. 3800 County Road 116, Hamel, MN 55340, USA

Phone: 763-478-8000 Sales@Tolomatic.com

3: IMA ACTUATOR PRODUCT CONFIGURATION

3.1 Tolomatic IMA Actuator Series Configuration

Tolomatic IMA Actuator Product Overview

- Four sizes: IMA22, IMA33, IMA44, IMA55
- Ball Screw Options: 5, 10, 20 and 25 mm lead
- Roller Screw Options: 4, 5 and 10 mm lead
- Motor windings: 230 Vac & 460 Vac
- IP65 standard; IP67 optional
- External Anti-Rotate
- Feedback choices (but not limited to):
 - Digital Incremental
 - Multi-turn Absolute Encoder
 - Resolver
- Connector choices (but not limited to):
 - DT1: Tolomatic Standard
 - DE1: Nidec/Control Tech., FM
 - DE2: Nidec/Control Tech., NT
 - DA1: Allen Bradley MP
 - DA2: Allen Bradley VP
 - DB1: Bosch Rexroth MSK
 - DL1: Lenze MCS
 - DS1: Siemens 1F



For performance data and specifications please refer to the Tolomatic IMA Actuator brochure #2700-4000

3.2 Standard Configurations and options



NOTE Please see Tolomatic <u>IMA Actuator brochure #2700-4000</u> for complete information on ordering codes. Use 3D CAD files (available at <u>www.tolomatic.com</u>) for critical dimensions.

IMA - Integrated Motor Actuator




Figure 3.1: Tolomatic IMA Actuator ordering codes and descriptions

14

3.2.1 Screw Selection

Tolomatic IMA Actuator: RN04, RN05, RN10: Roller nuts with 4mm, 5mm or 10 mm lead. BN05, BN10, BN20, BN25: Ball nuts with 5mm, 10mm, 20mm or 25mm lead Contact Tolomatic for application review and assistance in selecting a screw technology.

3.2.2 Motor Voltage

Available with 230 Vac or 460 Vac. With 1, and 3 stack windings. Contact Tolomatic for application review and assistance in selecting voltage and windings.

3.2.3 Internal Holding Brake Option

N=No Brake, B=24V Brake, 3= A spring held electronically released holding brake (parking brake) is available. The holding force of the brake is capable of holding the continuous force of the actuator. The brake is spring set and releases when voltage is applied to the brake. A separate power source is required.

3.2.4 Standard Mounting Options



Figure 3.2: Standard mounting for the IMA is four (4) threaded holes on the front face (rod end) of the actuator.

Standard mounting for the IMA is four (4) threaded holes on the front face (rod end) of the actuator. There are also Side Mounting Holes, 2 sides & bottom (no photo)

3.2.5 Mounting Options

Other mounting options include: Side mounting holes (a total of 12 mounting holes on both sides and bottom of actuator), mounting plates, rear clevis, front flange, front trunnion and rear trunnion.




Figure 3.3: Optional mounting for the Tolomatic IMA Actuator

3.2.6 Standard Rod End



Figure 3.4: Standard rod end for the IMA is internal threads.

3.2.7 Rod End Options

Other rod end options include: External threads, clevis, spherical eye and alignment coupler.



Figure 3.5: Rod End Options for the Tolomatic IMA Actuator



NOTE: ALC (Alignment Coupler) requires ARO (Anti-Rotate) for proper operation.

3.2.8 Other Options

Other IMA options available are: IP67 rating for protection against water and dust ingress; anti rotate option The IMA is available with a standard ingress rating of IP65. The IP67 option can be added to help further protect against water and dust ingress.




Figure 3.5: Rod End Options for the Tolomatic IMA Actuator

3.2.9 Special Options

Include: Longer stroke length other than standard; White Paint; Food Grade Grease; Hex Rod; Special Options

3.2.10 Feedback Device

Contact Tolomatic for application review and assistance in selecting feedback device. The IMA is offered with the following feedback device technologies as standard: Incremental, Resolver, and SICK Hiperface, SICK Hiperface DSL, and Heidenhain EnDat 2.2 multi-turn absolute feedback devices.

3.2.11 Cable & Connector(s)

Connectors are matched to selected feedback device. Contact Tolomatic for application review and assistance in selecting feedback device.

Cable Leads Information

CR5 and CR10: Cables are matched for each feedback / motor combination in 5 and 10 meter lengths.



In applications with lengths exceeding 10 meters for both feedback and power cables, there will be potential for

issues related to excessive feedback noise and partial discharge inception voltage (PDIV) that can break down the servo motor's insulation system eventually causing shorts.

3.2.12 Servo Drive

The Tolomatic IMA Actuators functions in the same way as a brushless servo motor. A servo drive is used to power and control the actuator. Please consult the servo drive manufacturer when sizing and selecting a servo drive for use with Tolomatic IMA Actuator.



The Tolomatic IMA Actuator must be ordered with all desired options. Field installation of options generally cannot be done. Call Tolomatic for complete details.

3.2.13 Rockwell Automation PartnerNetwork™ Program



Bronze Technology Partner

Tolomatic has aligned with Rockwell to provide customers with the best automation solutions for their motion control applications. Through the Encompass third-party product referencing program, you can quickly locate products that best solve your application challenges. Available Tolomatic products include the RSA, GSA, ERD, and IMA electric rod actuators and the MXE rodless screw drive and MXB rodless belt drive actuators. All these products are compatible with Rockwell Automation's servo products and extended motion control solutions. Visit Rockwell's PartnerNetworkTM Encompass program site for more information.

Enabled™ Technology Licensing Partner

The Rockwell Automation Enabled Technology partnership ensures that Tolomatic's IMA integrated servo motor actuators perform with the same compatibility as Rockwell servo motors. The results are the ability to integrate the Rockwell architecture to a larger variety of products to better service our customer base.

Tolomatic Resources

For additional information regarding the integration of the IMA to an Allen Bradley/Rockwell drive see:

TECH NOTE: Interfacing the Tolomatic IMA Actuator and Absolute Encoder with Allen Bradley Servo Drives: https://www.tolomatic.com/info-center/resource-details/324

SOFTWARE: IMA-Rockwell CMF (blb file) Import Tool: https://www.tolomatic.com/information-center/resource-details/687

TECH NOTE: IMA-Rockwell Logix CMF (blb file) File Import Instructions: https://www.tolomatic.com/info-center/resource-details/688

Tolomatic Last Revision: 2/4/2022

4: IMA MECHANICAL INSTALLATION

△WARNING

Before installation and commissioning of the equipment, this manual and all accompanying manufacturer documents and manuals MUST be completely read by the appropriate personnel. All warning texts must be given special attention.

4.1 Tolomatic IMA Actuator System Configuration

Tolomatic IMA Actuator series actuators incorporate an integral brushless servo motor. The design of the motor with the proper feedback device allows the IMA to be powered by nearly every brand of brushless drive on the market. This flexibility allows the IMA actuator to be used in the highest performing single and multi-axis motion control systems. It is recommended that all servo amplifiers and drives be selected based on the following important parameters:

- a) CE and UL approved system
- b) Thermal switch input
- c) Drive sizing key parameters for Tolomatic IMA Actuator
 - i) Peak current
- ii) Voltage
- iii) Peak RPM
- iv) Max current frequency




Figure 4.1: Typical connections for a single-axis system with an Tolomatic IMA Actuator with optional brake to a RSW servo system drive

4.2 General Operation

General Operation

The IMA actuator functions by translating the rotary motion of the integral brushless servo motor into linear motion using a screw mechanism. The linear travel, speeds and forces are controlled in conjunction with a brushless servo drive.

When ordered the IMA actuator can be configured with any one of the following feedback devices: Digital encoder, resolver, multi-turn absolute encoder. Please confirm you are using a version of software that supports the correct feedback device and operation of IMA actuators.

The relationship between the rotary motion of the motor and the linear motion of the actuator corresponds to the following relationships:

Linear distance traveled = (motor revolutions) * (screw lead)

Linear Speed = ([motor RPM]/60) * (screw lead)

Linear Thrust (kN) = Motor torque (Nm) * 2 * π * pitch (rev/mm) * screw efficiency

or

Linear Thrust (lbf) = Motor torque (in•lb) * 2 * π * pitch (rev/in) * screw efficiency

A CAUTION

Motor RMS current must be maintained at a level below the continuous current rating of the Tolomatic IMA Actuator or damage to the motor stator will result.

The peak current setting must be maintained at a level below the peak current rating of the Tolomatic IMA Actuator or damage to the motor stator will result.

A CAUTION

Care should be taken to not exceed the physical travel limits of the Tolomatic IMA Actuator. Doing so will cause the actuator to reach mechanical end of stroke internally. Although protected by the end of stroke bumpers, repeatedly reaching internal end of stroke can physically damage the screw and the internal components of the actuator.

A CAUTION

Power and Feedback cable lengths shall not exceed 10 meters. If the application requires cable lengths longer than 10 meters, please contact Tolomatic engineering for review.

4.3 Cold Temperature Startup Procedure

If startup ambient temperature is between 0-10 degrees Celsius, it is recommended to cycle the Tolomatic IMA Actuator (see recommended motion profile below) to bring the temperature up to operating temperature before proceeding with operating or calibrating the system. Initiating this startup procedure will lower the friction caused by cold temperatures and result in more accurate calibration of the system and better force repeatability performance during operation. If a motion profile other than recommended below will be used for the Cold Temperature Startup Procedure, contact Tolomatic for review of the motion profile before operating the actuator.

Recommended Motion Profile:

- Extend & retract full stroke of actuator at linear speed of 150 mm/sec for 5 or 4 mm lead screws and 300 mm/sec for 10 mm lead screws
- Dwell 1 second
- Repeat 75 times

4.4 Planning Your Installation

To operate the actuator in compliance with the relevant safety regulations maximum performance limits must be observed.

▲ CAUTION

When mounting your actuator in vertical or inclined positions be sure to include safety measures that control the

working mass should the drive screw fail. Uncontrolled moving masses can cause injury or damage to property. If the screw drive fails, due to wear or excessive load, gravity may cause the working mass to drop.

A CAUTION

For bench or fixture setup and testing of Tolomatic IMA Actuators, the actuator thrust rod must be anti-rotated by a fixture and the actuator securely retained to the bench or fixture. Never use a hand held wrench/device to provide the anti-rotate function while the motor is powered as contact with the internal end of stroke may send the wrench/device flying and may harm the operator or damage the actuator.

4.4.1 Alignment

Alignment of the actuator with respect to the application load and axis of motion is essential to minimize side loading. The IMA is not meant to be used in applications where side loading occurs as side loading will reduce the life of the actuator and rod seals.

4.4.2 Side Load Considerations

A CAUTION



Excessive side load on the output thrust rod of the actuator will dramatically reduce the life of the actuator and should be avoided. Side load can be caused from misalignment or loading that is not inline with the actuator output thrust rod.

The graph shows the maximum side load values for the Tolomatic IMA Actuators. Measures shall be established to limit any side loading that exceeds these values.

For maximum service life, external guiding is recommended to minimize side loading to the thrust rod and provide consistent alignment throughout service life.

IMA SIDE LOAD SPECIFICATIONS




Figure 4.2: Side load must not exceed maximum values represented by the lines in the graph

4.5 Mechanical Installation Instructions

- 1. Remove packaging
- 2. Carefully remove linear actuator from package. *Consider the weight of the actuator. Depending on the configuration, the actuator can weight up to approximately 42 kg (92.6 lb)





Figure 4.3: Do not carry IMA by connectors or cables.

A CAUTION

The Tolomatic IMA Actuator weight range is approximately 3.0 to 42 kg (6.6 to 92.6 lb). Special care must be taken when lifting this device. Do not carry by the connectors or cables. The connectors are not rated to support the weight of the actuator.



Figure 4.4: Use straps and winch to position heavy IMA actuator.

- 3. Visually inspect the actuator for damage
- 4. Notify the carrier of any shipping damage immediately
- 5. If the actuator is mounted in a vertical or inclined (sloping) position, include safety measures that control the work load in case of a screw failure.
- 6. Consider anti-rotation of the rod end. The actuator's thrust rod must be kept from rotating in order to achieve linear motion. If the application's tooling and load is free to rotate, order an IMA model with external anti-rotation (ARO) to prevent the rod from rotating.
- 7. It is recommended to install the actuator with rod-end down or at a downward inclination to achieve the best seal ingress protection.
- 8. Follow recommendations for actuator orientation and cable routing.
- 9. Ensure sufficient clearance around the actuator to allow for airflow and cooling.
- 10. Follow installation mounting considerations and specifications for each mounting configuration during installation.

4.6 Mounting

Thrust Rod Attachment

The design of the Tolomatic IMA Actuator allows the extending rod to rotate. This provides simple setup of the actuator by allowing the user to rotate the rod and thread it in and out of the actuator for mechanical attachment or system testing. This feature also requires that the rod be kept from rotating when used in its dedicated application to insure proper linear motion. In most applications, such as those where the load is coupled to an external mechanical guide, or some other support device, the load cannot rotate, and thus provides anti-rotation for the extending rod of the actuator.



Figure 4.5: Hold thrust rod stationary using a wrench on the flats of the rod end when attaching accessories, linkages or load to the actuator. Two wrenches are used here: The crescent wrench prevents the thrust rod from rotating, the torque wrench will fasten the spherical rod eye option to the actuator rod end. Torque values provided in Table 4.1

A CAUTION

Take precautions to cause no damage to the actuator's grease zerk throughout the following process.

△WARNING

APPLYING TORQUE TO THE THRUST ROD MAY DAMAGE THE ACTUATOR. Avoid this by using a wrench to prevent the thrust rod from rotating while attaching the load, linkages or accessories to the rod end. When attaching the load, linkages or accessories to the rod end, it is recommended to have the thrust rod fully retracted.

Thrust Rod Connection:

ROD END ATTACHMENT FOR ROUND ROD ACTUATOR: Hold flats on round rod stationary using a fixture, vise, or opposing wrench. Torque weld gun connection linkage or rod eye up to table value shown:

ROD END ATTACHMENT FOR ACTUATOR WITH ARO OPTION: Hold flats on the thrust rod stationary using a fixture, vise, or opposing wrench. Do not rely on the anti-rotate feature to oppose the installation torque.

Torque rod end linkage or rod eye up to table value shown:

Internal Threads

| M8 | 11 N-m | M12 |
|----|---------|-----|
| | 8 ft-lb | |

| M12 | 70 N-m |
|-----|----------|
| | 52 ft-lb |

| M20 | 180 N-m |
|-----|-----------|
| | 133 ft-lb |

| M27 | 500 N-m |
|-----|-----------|
| | 369 ft-lb |

External Threads (MET)

| EXCOLLIGI | TITIOGGO (IVIL I |
|-----------|------------------|
| M10 | 14 N-m |
| | 10 ft-lb |

| M16 | 90 N-m |
|-----|----------|
| | 67 ft-lb |

| M20 | 180 N-m |
|-----|-----------|
| | 133 ft-lb |

| M27 | 500 N-m |
|-----|-----------|
| | 369 ft-lb |

Table 4.1: Rod end torque recommendations

Tapped Hole Mounts Recommended Torque

Front / Rear / Side Mount Holes

| M6 | 3 N-m | M8 | 30 N-m |
|----|---------|----|----------|
| | 2 ft-lb | | 22 ft-lb |

| M12 | 85 N-m |
|-----|----------|
| | 63 ft-lb |

Table 4.2: Tapped hole torque recommendations

Mounting Plate (MP2) Clearance Hole Bolt and Torque Requirements (Minimum Fastener Grade 8.8)

| M8 | 11 N-m |
|---------|---------|
| (IMA22) | 8 ft-lb |

| M10 | 30 N-m |
|-------------|----------|
| (IMA 33/44) | 22 ft-lb |

| M14 | 100 N-m |
|---------|----------|
| (IMA55) | 74 ft-lb |

Table 4.3: Mounting Plate (MP2) Clearance Hole Bolt and Torque Requirements (Minimum Fastener Grade 8.8)

Front Flange Mount (FFG) Clearance Hole Bolt and Torque Requirements (Minimum Fastener Grade 8.8)

| M8 | 11 N-m | M12 | 26 N-m | 1 | M14 | 100 N-m | M16 | 115 N-m |
|---------|---------|---------|----------|---|---------|----------|---------|----------|
| (IMA22) | 8 ft-lb | (IMA33) | 19 ft-lb | | (IMA44) | 74 ft-lb | (IMA55) | 85 ft-lb |

Table 4.4: Front Flange Mount (FFG) Clearance Hole Bolt and Torque Requirements (Minimum Fastener Grade 8.8)

4.5 Field Installation of ARO (Anti Rotation) Option

The design of the IMA actuator allows the extending rod to rotate. This provides simple setup of the actuator by allowing the user to rotate the rod and thread it in and out of the actuator for mechanical attachment or system testing. This feature also requires that the rod be kept from rotating when used in its dedicated application to insure proper linear motion. In most applications, such as those where the load is coupled to linear bearings, or some other support device, the load cannot rotate, and thus provides anti-rotation for the extending rod of the actuator. For applications in which the load is free to rotate, Tolomatic offers the anti-rotation systems shown below.

∆WARNING

The anti-rotate option (ARO) is not a guide or support mechanism. It is intended only as an anti-rotate device.




Figure 4.6: View of ARO (Anti Rotate Option)

ARO ATTACHMENT PROCEDURE / GUIDELINES

Recommended tools: 4, 5, 6 and 10 mm hex keys (allen wrenches), small dead-blow hammer.

A CAUTION

Improper alignment of the anti-rotate shaft may result in binding and / or side loading which may reduce the life of the actuator.

A CAUTION

Take precautions to cause no damage to the actuator's grease zerk throughout the following process.

- 1. Assemble Fastener [#3] into the Anti-Rotate Clamp [#2] finger-tight, then back off one (1) turn.
- Assemble Anti-Rotate Clamp [#2] onto Rod End [#5] orientated such that the shallow counterbore faces the
 non-working end of the actuator and the clamp's opening straddles the Grease Zerk [#4]. Engage the flats of
 the Anti-Rotate Clamp [#2] with the flats of the Rod End [#5]. Light tapping with a dead-blow hammer may be
 necessary to seat the Anti-Rotate Clamp [#2] up against the thrust tube. When ensuring the Anti-Rotate
 Clamp [#2] doesn't shift, torque the Fastener [#3] to:
 IMA22, IMA33, IMA44 = 69 in-lbs (7.8 N-m); IMA55 = 180 in-lbs (20.3 N-m).
- 3. Apply medium strength thread-locker to the two (2) Fasteners [#8]. Using the two (2) Fasteners [#8] and two (2) Washers [#7], assemble the Bearing Block [#6] onto the actuator finger-tight only, orientated such that the Bearing Block [#6] does not breech the face of the actuator.
- 4. Insert the Anti-Rotate Shaft [#9] through the Bearing Block [#6] orientated with the shaft's tapped hole facing the working end of the actuator. Light tapping with the dead-blow hammer may be necessary to get the Anti-Rotate Shaft [#9] through the oil wick of the Bearing Block [#6].
- 5. Manually rotate the thrust rod to retract the actuator as far as the application allows without mechanically stopping or striking any mounting means.
- 6. Ensure that the Bearing Block Fasteners [#8] are just finger tight allowing the Bearing Block [#6] to float. Align the shallow counterbore of the Anti-Rotate Clamp [#2] with the Anti-Rotate Shaft [#9], engage the shaft into the counterbore. Apply medium strength thread-locker to the Fastener [#1] and assemble through the Anti-Rotate Clamp [#2] and into the Anti-Rotate Shaft [#9].

 Torque to: IMA22 = 69 in-lbs (7.8 N-m); IMA33, IMA44, IMA55 = 117 in-lbs (13.2 N-m).
- 7. Torque the two (2) Bearing Block Fasteners [#8] to: IMA22 = 117 in-lbs (13.2 N-m) IMA33, IMA44 = 350 in-lbs (39.5 N-m) IMA55 = 840 in-lbs (95.0 N-m).

5: ELECTRICAL INSTALLATION

5.1 Connector Orientation

The IMA is manufactured with both the power and feedback connectors facing forward (toward rod end). The standard Tolomatic connectors are shown in figure 5.2 below. Tolomatic can mount the connectors in the orientation desired by the customer, or be rotated during installation. The Tolomatic IMA Actuator is manufactured to fit many different connector configurations. Many drive manufacturers have specific connectors/pinout/wiring for integrating the Tolomatic IMA Actuator into operation. Reference 5.4 for available configurations. Depending on the connector choice, some connectors may be rotated from -90° to 180°.

For the Tolomatic standard connectors it is not necessary to loosen the screws retaining the connectors. Just carefully rotate to the desired orientation.



Do not apply excessive force while rotating connectors.




Figure 5.3: Connector rotation. Note that the Tolomatic standard connectors may be rotated from -90° to +180° allowing for cables to connect toward the front (rod end, as manufactured), to either side, both sides, or back of actuator.




Figure 5.4: Drawing of box mount connectors used on some Tolomatic IMA Actuators.

See individual encoder/connector in section 5.4 for details.

5.2 Feedback Information

IMA actuators may use a digital encoder, multi-turn absolute encoder or a single-pole resolver as the rotary feedback device. The selection of the feedback device is dictated by the drive used to operate the actuator. Each drive has specific requirements for the feedback on the motor. Not all resolver-based drives can use the same resolver, resolver alignment, or relative direction of resolver rotation. Not all encoder-based drives can use the same encoder, encoder alignment or relative direction of encoder rotation. Many drives offer software that allows the entering of parameters or the downloading of "motor data files" that dictate how the feedback must be set up on the motor. Tolomatic can provide many of these "data files" or the proper parameters to enter. Entering motor parameter data to some drives may require assistance from the drive manufacturer.

5.3 Feedback Commutation

When Tolomatic manufactures a Tolomatic IMA Actuator, the proper feedback is selected, mounted, aligned and test run on a servo system drive that is known to be equivalent to the servo system drive that the customer plans to use for confirming proper feedback alignment and operation.

A CAUTION

In any case where it is determined that the feedback has become misaligned, or an drive change is made requiring the feedback to be aligned differently, it is recommended that Tolomatic be contacted and arrangements made to have that procedure performed.

| Feedback Type | Offset Alignment | Electrical Degree Tolerance |
|---------------------|------------------|-----------------------------|
| Hiperface | 0 Degrees | +/- 5 Degrees |
| Hiperface DSL | 0 Degrees | +/- 5 Degrees |
| Endat 2.2 | 0 Degrees | +/- 5 Degrees |
| Incremental Encoder | 30 Degrees | +/- 5 Degrees |
| Resolver | 90 Degrees | +/- 5 Degrees |

5.4 Feedback Commutation Details

Terminology in the industry varies from motor supplier to motor supplier. One example is in the labeling of phases; some suppliers will reference phase R, S and T while others refer to U, V and W. With the differences in terminology visual explanations are used for clarification purposes.

Tolomatic Tolomatic IMA Actuator motors are wired such that as the torque generating current vector progresses from phase U -> V -> W positive rotation is created. Positive rotation is defined as clockwise as viewed from the front face of the actuator. For reference, positive rotation will cause the thrust rod to extend.




Figure 5.5: Thrust rod movement relative to motor rotation

Absolute Encoder Feedback

The standard commutation offset for the absolute encoders offered in the IMA is set at 0 electrical degrees. This is accomplished by first locking the motor rotor with a current vector from phase U (+) to phase V and W (-), and then sending a set-zero position command to the encoder using appropriate programming tool.

Digital Quadrature Encoder Feedback

The IMA standard feedback device is a digital quadrature encoder. This encoder utilizes differential A and B signals for tracking position and differential index pulse and halls for commutation. The encoder is mounted with a current vector from phase R to phase T, at this commutation angle the index pulse of the encoder is located and the encoder is locked to the shaft of the motor.




Figure 5.6: Back EMF Voltage vs Electrical Angle

From a manufacturing viewpoint the utilization of a fixed current vector provides the simplest means for aligning a feedback device. Some manufacturers however will reference a motor's back emf when discussing commutation angles. This is due to the ability to quantify via measurement the alignment of a feedback device. With that in mind; when measuring the back emf phase to phase of the winding the following can be verified on an IMA.




Figure 5.7: Back EMF Voltage Phase to Phase vs Electrical Angle

The quadrature output of the encoder will be such that the rising edge of the A channel leads the rising edge of the B channel with positive rotation as defined in the graph above.

The halls are configured such that the falling edge of the U channel coincides with the index pulse location. The graph at right shows the relationship of the halls to the phase to phase back emf. The halls have an offset of 30 electrical degrees.




Figure 5.8: Hall Alignment

Resolver Feedback

The Tolomatic IMA Actuator family is also offered with resolver feedback. A resolver must be excited with a sinusoidal Input and outputs two signals, commonly referred to as cos and sin. These signal's magnitude and the phase angle relative to the excitation voltage are used by the drive to determine the absolute position (single rotational) of the motor's armature.

These actuators are aligned with a current vector from phase V (+) to phase W (-). At this location, the resolver body is rotated until the cos signal is null, and the sin signal is in phase with the excitation frequency.




Figure 5.9: Motor rotational position at 0

Direction can be confirmed by rotating the shaft clockwise as viewed from the back, where, after 90 degrees of rotation the cos will now be in phase with the excitation frequency and the sin signal will be null.




Figure 5.10: Motor rotational position at 90

Servomotor Information:



For performance data and specifications please refer to the Tolomatic IMA Actuator brochure #2700-4000

5.5 Feedback Specifications

| ALL SIZES | |
|-----------------|------------------------|
| DIGITAL | Quantum |
| ENCODER | |
| Input Voltage | 5 VDC (+/-5%) |
| | |
| Input Current | 125 mA Typical |
| Output Circuits | AM26LS31 (RS422 line |
| | Driver) |
| Output Format | Quadrature, 2000 line, |
| | with commutation |

| ALL SIZES | |
|---------------------|---------------------|
| ABSOLUTE | Stegmann SKM36 |
| (Dx1A1x) | |
| Output Type | Hiperface MultiTurn |
| | Absolute |
| Input Voltage | 7-12 VDC |
| Max NL Operating | 60 mA |
| Current | |
| Sin/Cos Resolution | 128 periods per |
| | revolution |
| Absolute Resolution | 4096 revs with 4096 |
| | steps per rev |

| ALL SIZES | |
|---------------------|-------------------------------|
| ABSOLUTE | Stegmann |
| (DA2A2x) | EKM36 |
| Output Type | Hiperface DSL |
| | MultiTurn |
| | Absolute |
| Input Voltage | 7-12 VDC |
| Max NL Operating | 150 mA |
| I Max INL Operating | 130 1117 |
| Current | 130 111A |
| | 4096 revs with |
| Current | |
| Current Absolute | 4096 revs with |
| Current Absolute | 4096 revs with 262, 144 steps |

| ALL SIZES | |
|----------------------|---------------------------|
| ABSOLUTE | Heidenhain EQN1025 |
| (Dx1H1x) | |
| Interface | EnData 2.2 MultiTurn |
| | Absolute |
| | |
| Ordering Designation | EnDat01 |
| Input Voltage | 3.6 - 14 VDC |
| | |
| Current Consumption | 5V: 105mA |
| Тур | |
| | |
| Resolution | 4096 revs with 8192 steps |
| | per rev |

| IMA22, IMA33, IMA44, IMA55 | | | | |
|----------------------------|------------------|--|--|--|
| RESOLVER | Dynapar BRC | | | |
| Input Voltage | 7 Vrms (+/- 10%) | | | |
| Excitation | 10 kHz | | | |
| Frequency | | | | |
| Max Input Current | 40 mA | | | |
| Transformation | 0.5 (+/-10%) | | | |
| Ratio | | | | |
| Impedance [ZRO] | 205 Ohms | | | |
| Impedance [ZRS] | 187 Ohms | | | |
| Impedance [ZSO] | 495 Ohms | | | |
| Impedance [ZSS] | 447 Ohms | | | |

| IMA22, IMA33, IMA44, IMA55 | | | | |
|----------------------------|-----------------|--|--|--|
| RESOLVER | Dynapar BRX | | | |
| Input Voltage | 4 Vrms (+/- 5%) | | | |
| Excitation Frequency | 5 kHz | | | |
| | | | | |
| Max Input Current | 45 mA | | | |
| Transformation Ratio | 0.5 (+/-10%) | | | |
| | | | | |
| Impedance [ZRO] | 129 Ohms | | | |
| Impedance [ZRS] | 120 Ohms | | | |
| Impedance [ZSO] | 461 Ohms | | | |
| Impedance [ZSS] | 427 Ohms | | | |

5.6 Thermal Sensor Specifications

Most of the motor windings have an integral normally closed thermal switch. The switch opens at a temperature of 100°C (212° F), which is the windings maximum operating temperature. The Rockwell VPL connector (DA2) will include a Vishay Thermistor for measuring the temperature. The Siemens connector (DS1) will include a PT1000 thermistor for measuring the temperature. The thermal switch/sensor is meant to protect the windings, the actuators continuous operating region must still be obeyed. Cycles that cause the windings temperature to approach 100°C (212° F) will reduce the expected life of the actuator.

| All Except DS1 | |
|----------------|---------|
| Thermal Switch | |
| Opens at: | 100°C |
| | (212°F) |
| Recommended | 1.0 ADC |
| Current | |
| Max Voltage | 14 VDC |
| | |

| DS1 (Siemens) | |
|-------------------|-------------|
| PT1000 Thermal Tr | ansistor |
| Make / Model | TE |
| | PTFD102B1G0 |
| Nominal Resi- | 1000 Ohms |
| stance @ 0° C | |
| Temp Coefficient | 3850 ppm |
| of Resistance | |
| Measuring | 0.5 mA |
| Current | |

| DA2 (Rockwell VPL) | | | | |
|--------------------|-----------|--|--|--|
| Vishay | | | | |
| Make/Model | NTCLE213- | | | |
| | E3103FLyy | | | |
| Nominal Resi- | 1000 Ohms | | | |
| stance @ 0° C | | | | |
| Temp Coefficient | 3850 ppm | | | |
| of Resistance | | | | |
| Measuring | 0.5 mA | | | |
| Current | | | | |

△WARNING

- Don't exceed rated motor voltage.
- Refer to Servo Drive User Manual for wiring instructions.
- Electrical connections and cabling should receive special attention during component selection and system design when utilizing servo motor controlled systems. The feedback cable consists of twisted pairs of wires in addition to an outer cable shield.
- Improperly wiring the feedback cable can cause unstable operation, incorrect operation or no operation at all.
- In some cases, improper current limits set in the drive, along with incorrect wiring of the feedback cable can lead to damage of the motor.


30

5.7 Connector Pinouts



NOTE: The IMA is manufactured with your choice of several different connectors to be compliant with popular motor and drive manufacturers. Be sure to also reference all manufacturer material to insure proper connections.

5.7.1 Tolomatic Standard - DT1



| 5.7.1.1 Motor Powe | r Connector - DT1xxx |
|--------------------|----------------------|
|--------------------|----------------------|

Manufacturer: Intercontec

Intercontec Part No.: BEDC 106 MR14 00 1216 000

| intercontect i art ivo | | |
|------------------------|--|--|
| Name | | |
| Phase R | | |
| Phase S | | |
| GND** | | |
| Phase T | | |
| * BR+ | | |
| * BR- | | |
| | | |

^{**}Required

| 5.7.1.2 | Motor | Power | Cable | Wiring |
|---------|-------|--------------|-------|--------|
|---------|-------|--------------|-------|--------|


| MV4x (460V) – NO Brake | | | |
|------------------------|-----|-------------------|-----|
| Cable | | | |
| Part No.: | CR1 | 10 10m: 2733-1221 | |
| Wire Color Signal Name | | Signal Name | Pin |
| BLK - 1 | | Phase R | 1 |
| BLK - 2 | | Phase S | 2 |
| GRN/YEL | | Ground | 3 |
| BLK - 3 | | Phase T | 4 |

| MV4x (460V) – NO Brake | | | |
|------------------------|-----|------------------|---|
| Cable | | 5 5m: 2733-1611 | |
| Part No.: | CR1 | 0 10m: 2733-1221 | |
| Wire Color Signal Name | | Pin | |
| BLK - 1 | | Phase R | 1 |
| BLK - 2 | | Phase S | 2 |
| GRN/YEL | | Ground | 3 |
| BLK - 3 | | Phase T | 4 |

| MV4x (460V) – WITH Brake | | | |
|--------------------------|------|------------------|-----|
| Cable | | | |
| Part No.: | CR1 | 0 10m: 2733-1222 | |
| Wire C | olor | Signal Name | Pin |
| BLK - | 1 | Phase R | 1 |
| BLK - 2 | | Phase S | 2 |
| GRN/YEL | | Ground | 3 |
| BLK - 3 | | Phase T | 4 |
| BLK (20 AWG) | | Brake + | 5 |
| WHT (20 AWG) | | Brake - | 6 |

| MV2x (230V) – WITH Brake | | | |
|--------------------------|------|-------------------|-----|
| Cable CR5 5m: 2744-1489 | | | |
| Part No.: | CR1 | 10 10m: 2744-1222 | |
| Wire C | olor | Signal Name | Pin |
| BLK - 1 | | Phase R | 1 |
| BLK - 2 | | Phase S | 2 |
| GRN/YEL | | Ground | 3 |
| BLK - 3 | | Phase T | 4 |
| RED (18 AWG) | | Brake + | 5 |
| BLK (18 AWG) | | Brake - | 6 |

^{*} Connect brake only when present



5.7.1.3 Digital Incremental Connector - DT1 D1x


Manufacturer: Intercontec

Intercontec Part No.: AEDC 113 MR83 00 1215 000

| intercontect a | | |
|----------------|---------|--|
| Pin | Name | |
| 1 | Temp - | |
| 2 | Temp + | |
| 3 | NC | |
| 4 | Hall U | |
| 5 | Hall U- | |
| 6 | Hall V | |
| 7 | Hall V- | |
| 8 | Hall W | |
| 9 | Hall W- | |

| Pin | Name |
|-----|--------|
| 10 | A+ |
| 11 | + |
| 12 | - |
| 13 | A- |
| 14 | B+ |
| 15 | B- |
| 16 | +5 Vdc |
| 17 | Com |

| 5.7.1.4 Digital Incremental Cable Wiring (Flying Leads) | | | |
|---|------------------|----------------|------|
| for DT1 D1x IMA22, IMA33, IMA44 & IMA55 | | | |
| | Cable Part No.: | CR5 5m: 2733- | 1614 |
| | | CR10 10m: 2733 | |
| Wire Color | | Signal Name | Pin |
| WHT | Pair 8 (0.34mm2) | Temp - | 1 |
| BRN | Pair 8 (0.34mm2) | Temp + | 2 |
| Shield | | Shield | 3 |
| GRN | Pair 2 | Hall U | 4 |
| YEL | Pair 2 | Hall U- | 5 |
| GRY | Pair 3 | Hall V | 6 |
| PNK | Pair 3 | Hall V- | 7 |
| BLK | Pair 4 | Hall W | 8 |
| VIO | Pair 4 | Hall W- | 9 |
| GRY/PNK | Pair 5 | A+ | 10 |
| WHT/GRN | Pair 6 | + | 11 |
| BRN/GRN | Pair 6 | - | 12 |
| RED/BLU | Pair 5 | A- | 13 |
| RED | Pair 7 | B+ | 14 |
| BLU | Pair 7 | B- | 15 |
| RED | Pair 1 (0.5mm2) | +5Vdc | 16 |
| BLU | Pair 1 (0.5mm2) | COM | 17 |




| 5.7.1.5 Resolver - DT1 R1x |
|---|
| Manufacturer: Intercontec |
| Intercontec Part No.: AEDC 052 MR83 00 1215 000 |

| intercontect art No7 | | |
|----------------------|--|--|
| Signal Name | | |
| Excite | | |
| Excite Lo | | |
| Cos | | |
| Cos Lo | | |
| Sin | | |
| Sin Lo | | |
| Temp + | | |
| Temp - | | |
| NC | | |
| | | |

| 5.7.1.6 Resolver Cable Wiring (Flying Leads) for DT1 R1 | | | | |
|---|-----------------------|---------------------|----------|--------|
| IMA22, IMA33, IMA44 & IMA55 | | | | |
| Cable Part No.: | | CR5 | 5m: 2733 | 3-1613 |
| | | CR10 10m: 2733-1223 | | 3-1223 |
| | Wire Color | Sigr | nal Name | Pin |
| RED | Pair 1 | E | xcite | 1 |
| GRY | Pair 2 | Ex | cite Lo | 2 |
| PNK | Pair 2 | | Cos | 3 |
| BLU | Pair 1 | С | os Lo | 4 |
| VIO | Pair 3 | | Sin | 5 |
| BLK | Pair 3 | 9 | Sin Lo | 6 |
| GRN | Pair 4 | Т | emp + | 7 |
| YEL | Pair 4 | Т | emp - | 8 |
| Shield | | | Shield | 9 |
| WHT | (0.5mm ²) | | NC | 10 |
| NC | | | NC | 11 |
| BRN | (0.5mm ²) | | NC | 12 |
| NOTE: NC = no connection | | | | |

Brake Information: 24 Vdc power is required to release the brake during operation. Ensure that pins 5 and 6 in the power connector are used for the brake.



5.7.1.7 Multi-turn Absolute Encoder - DT1 A1x

Manufacturer: Intercontec

Intercontec Part No.: AEDC 052 MR83 00 1215 000


| intorocitios i dicito | | |
|-----------------------|--|--|
| Name | | |
| REFCOS | | |
| Data+ | | |
| Data- | | |
| +COS | | |
| +SIN | | |
| REFSIN | | |
| Temp + | | |
| Temp - | | |
| NC | | |
| COM | | |
| NC | | |
| Vcc | | |
| | | |

5.7.1.8 Multi-turn Absolute Encoder Cable Wiring(Flying Leads) for DT1 A1x

| ٠. | | | | | |
|----|-----------------------------|-----------------------|---------------------|-------------|--|
| | IMA22, IMA33, IMA44 & IMA55 | | | | |
| | Cable Part No.: | | CR5 5m | : 2733-1613 | |
| | 0.0 | .5.0 1 4.1 1 10 | CR10 10m: 2733-1223 | | |
| | Wir | e Color | Signal Name | Pin | |
| | RED | Pair 1 | REFCOS | 1 | |
| | GRY | Pair 2 | Data + | 2 | |
| | PNK | Pair 2 | Data - | 3 | |
| | BLU | Pair 1 | + Cos | 4 | |
| | VIO | Pair 3 | + Sin | 5 | |
| | BLK | Pair 3 | REFSIN | 6 | |
| | GRN | Pair 4 | Temp + | 7 | |
| | YEL | Pair 4 | Temp - | 8 | |
| | Shield | | Shield | 9 | |
| | WHT | (0.5mm ²) | COM | 10 | |
| | NC | | NC | 11 | |
| | BRN | (0.5mm ²) | Vcc | 12 | |
| _ | TE NO. | | | | |

NOTE: NC = no connection

Brake Information: 24 Vdc power is required to release the brake during operation. Ensure that pins 5 and 6 in the power connector are used for the brake.



5.7.1.9 MultiTurn Absolute Encoder - DT1 H1x

Manufacturer: Intercontec

Intercontec Part No.: AEDC 113 MR83 00 1215 000

| Pin | Name | |
|-----|-----------|--|
| 1 | Temp – | |
| 2 | Temp + | |
| 3 | NC | |
| 4 | NC | |
| 5 | NC | |
| 6 | NC | |
| 7 | NC | |
| 8 | Enc Clk+ | |
| 9 | Enc Clk – | |


| Pin | Name |
|-----|------------|
| 10 | B+ |
| 11 | Enc Data + |
| 12 | Enc Data – |
| 13 | B – |
| 14 | A + |
| 15 | A – |
| 16 | UP |
| 17 | 0 V |
| | |

5.7.1.10 MultiTurn Absolute Encoder Cable Wiring (FlyingLeads) for DT1 H1x $\,$

| IMA22, IMA33, IMA44 & IMA55 | | | |
|-----------------------------|-------------------------------|-------------|--------------|
| | Cable Part No.: | CR5 5m | : 2733-1614 |
| | Cable Falt No | CR10 10n | n: 2733-1224 |
| Wire | Color | Signal Name | Pin |
| WHT | Pair 8 (0.34mm ²) | PT 1000 | 1 |
| RED | Pair 8 (0.34mm ²) | PT 1000 | 2 |
| YEL | /GRN | Shield | 3 |
| GRN | Pair 2 | NC | 4 |
| YEL | Pair 2 | NC | 5 |
| GRY | Pair 3 | NC | 6 |
| PNK | Pair 3 | NC | 7 |
| BLK | Pair 4 | Enc Clk + | 8 |
| VIO | Pair 4 | Enc Clk – | 9 |
| GRY/PNK | Pair 5 | B + | 10 |
| WHT/GRN | Pair 6 | Enc Data + | 11 |
| BRN/GRN | Pair 6 | Enc Data – | 12 |
| RED/BLU | Pair 5 | B – | 13 |
| RED | Pair 7 | A + | 14 |
| BLU | Pair 7 | A – | 15 |
| RED | Pair 1 (0.5mm ²) | Up | 16 |
| BLU | Pair 1 (0.5mm ²) | 0 V | 17 |

Brake Information: 24 Vdc power is required to release the brake during operation. Ensure that pins 5 and 6 in the power connector are used for the brake.

5.7.2 Allen Bradley MP Motor Series - DA1




| 5 | 5.7.2.1 Motor Power Connector DA1 xxx | | |
|----|---|------|--|
| N | Manufacturer: Intercontec | | |
| Ir | Intercontec Part No.: BECD 091 MR30 00 1216 000 | | |
| | | N.I. | |

| Pin | Name |
|-----|---------|
| Α | Phase R |
| В | Phase S |
| С | Phase T |
| D | GND** |
| Е | NC |
| F | BR+* |
| G | BR- * |
| Н | NC |
| L | NC |
| • | |

**Required

*Connect brake only when present



5.7.2.2 Multi-turn Absolute Encoder Connector Manufacturer: Intercontec intercontec Part No.: AEDC 113 MR04 00 1215 000


| intercontec Part No.: AEI | |
|---------------------------|-------------|
| MV2x (230V) | |
| Pin | Signal Name |
| 1 | + SIN |
| 2 | REFSIN |
| 3 | +COS |
| 4 | REFCOS |
| 5 | DATA + |
| 6 | DATA - |
| 7 | NC |
| 8 | NC |
| 9 | +5 VDC |
| 10 | COM |
| 11 | NC |
| 12 | NC |
| 13 | TEMP + |
| 14 | TEMP - |
| 15 | NC |
| 16 | NC |
| 17 | NC |
| | |

| | MV4x (460V) |
|-----|-------------|
| Pin | Signal Name |
| 1 | + SIN |
| 2 | REFSIN |
| 3 | +COS |
| 4 | REFCOS |
| 5 | DATA + |
| 6 | DATA - |
| 7 | NC |
| 8 | NC |
| 9 | NC |
| 10 | NC |
| 11 | +9 VDC |
| 12 | COM |
| 13 | TEMP + |
| 14 | TEMP - |
| 15 | NC |
| 16 | NC |
| 17 | NC |

NOTE: NC = no connection

Brake Information: 24 Vdc power is required to release the brake during operation. Ensure that pins F and G in the power connector are used for the brake.

5.7.3 Allen Bradley VP Motor Series - DA2



| 5.7.3.1 Motor Power Connector DA2 xxx | | | |
|---------------------------------------|-------------------|----------------------------------|--|
| Manufacturer: Intercontec | | | |
| Interc | ontec Part No.: E | BECD 091 MR30 00 1216 000 | |
| Pin | Name | | |
| Α | Phase R | | |
| В | Phase S | *** | |
| С | Phase T | **Required | |
| D | GND** | | |
| Е | U + / DSL + | | |
| F | BR+* | *Connect brake only when present | |
| G | BR- * | | |
| Н | GND / DSL - | | |
| L | NC | | |

Brake Information: 24 Vdc power is required to release the brake during operation. Ensure that pins F and G in the power connector are used for the brake.

Thermal Device: Motor equipped with Vishay temperature sensor. Tolomatic recommends the use of the thermal switch in order to protect the actuator in higher ambient temperatures.


△WARNING

Encoder temp is not a way to monitor motor temperature. Performance is based on actuator performance.

△WARNING


In some cases, improper current limits set in the drive, along with incorrect wiring of the feedback cable can lead to damage of the motor.

5.7.4 Bosch Rexroth MSK Motor Series - DB1



| 5.7.4.1 Motor Power Connector - DB1xxx | | | | | |
|--|-----------------------------|--|-----|--------|--|
| Manu | Manufacturer: Bosch Rexroth | | | | |
| Bosch Rexroth Part No.: 911 309687 (RLS1100/C02) | | | | | |
| Pin | Name | | Pin | Name | |
| U1 | Phase R | | 6 | Temp - | |
| V1 | Phase S | | 7 | * BR+ | |
| W1 | Phase T | | 8 | * BR- | |
| PE | GND** | | 9 | NC | |
| 5 | Temp + | | | | |

^{*}Connect brake only when present **Required



| 5.7.4.2 Multi-turn Absolute Encoder Connector - DB1 A1x | |
|---|--|
| Manufacturer: Bosch Rexroth | |

Bosch Rexroth Part No.: 911 309733 (RGS1100/C02)

| Pin | Signal Name |
|-----|-------------|
| 1 | Vcc |
| 2 | Com |
| 3 | +COS |
| 4 | REFCOS |
| 5 | +SIN |

| Pin | Signal Name |
|-----|-------------|
| 6 | REF SIN |
| 7 | Data+ |
| 8 | Data- |
| 9 | NC |
| 10 | NC |

Tolomatic Last Revision: 2/4/2022


NOTE: NC = no connection

Brake Information: 24 Vdc power is required to release the brake during operation. Ensure that pins 7 and 8 in the power connector are used for the brake.

Thermal Device: Motor equipped with thermal switch at 100C. Tolomatic recommends the use of the thermal switch in order to protect the actuator in higher ambient temperatures.

38

5.7.5 Control Techniques FM Motor Series - DE1



| 5.7.5.1 | Motor | Power | Connector - DE1xxx |
|---------|-------|-------|--------------------|
| | | | |


Manufacturer: Intercontec

Intercontec Part No.: BEDC 106 MR14 00 1216 000

| intercentact artitori | | |
|-----------------------|---------|--|
| Pin | Name | |
| 1 | Phase R | |
| 2 | Phase S | |
| 3 | GND** | |
| 4 | Phase T | |
| 5 | * BR+ | |
| 6 | * BR- | |

**Required

*Connect brake only when present




5.7.5.2 Digital Incremental Connector - DE1 D1x

Manufacturer: Intercontec

Intercontec Part No.: AEDC 113 MR83 00 1216 000

| intercontec Part No. | | | | |
|----------------------|---------|--|--|--|
| Pin | Name | | | |
| 1 | Temp - | | | |
| 2 | Temp + | | | |
| 3 | NC | | | |
| 4 | Hall U | | | |
| 5 | Hall U- | | | |
| 6 | Hall V | | | |
| 7 | Hall V- | | | |
| 8 | Hall W | | | |
| 9 | Hall W- | | | |
| 10 | A+ | | | |
| 11 | + | | | |
| 12 | l- | | | |
| 13 | A- | | | |
| 14 | B+ | | | |
| 15 | B- | | | |
| 16 | +5 Vdc | | | |
| 17 | Com | | | |
| | | | | |

Brake Information: 24 Vdc power is required to release the brake during operation. Ensure that pins 5 and 6 in the power connector are used for the brake.




5.7.5.3 Resolver Connector - DE1 R1x

Manufacturer: Intercontec

Intercontec Part No.: AEDC 052 MR83 00 1215 000

| mitoroomtoo i dirittom ileb | | | |
|-----------------------------|-------------|--|--|
| Pin | Signal Name | | |
| 1 | Exc | | |
| 2 | Exc Lo | | |
| 3 | Cos | | |
| 4 | Cos Lo | | |
| 5 | Sin | | |
| 6 | Sin Lo | | |
| 7 | Temp + | | |
| 8 | Temp - | | |
| 9 | NC | | |
| 10 | NC | | |
| 11 | NC | | |
| 12 | NC. | | |



5.7.5.4 Multi-turn Absolute Encoder - DE1 A1x

Manufacturer: Intercontec


Intercontec Part No.: AEDC 052 MR83 00 1215 000

| Pin | Name |
|-----|--------|
| 1 | REFCOS |
| 2 | Data+ |
| 3 | Data- |
| 4 | +COS |
| 5 | +SIN |
| 6 | REFSIN |
| 7 | Temp + |
| 8 | Temp - |
| 9 | NC |
| 10 | COM |
| 11 | NC |
| 12 | Vcc |

NOTE: NC = no connection

Brake Information: 24 Vdc power is required to release the brake during operation. Ensure that pins 5 and 6 in the power connector are used for the brake.


5.7.6 Control Techniques NT Motor Series - DE2



| _ | |
|---|---|
| | 5.7.6.1 Motor Power Connector - DE2 xxx |
| | Manufacturer: Amphenol |
| | Amphenol Part No.: PT02E-16-8P(025) |

| Pin | Name | |
|-----|-------|---|
| Α | R | |
| В | S | |
| С | T | * |
| D | GND** | |
| Е | NC | |
| F | NC | |
| G | NC | |
| Н | NC | |
| | | |

**Required



5.7.6.2 Digital Incremental Encoder Connector - DE2 D1x Manufacturer: Amphenol Amphenol Part No.: PT02E-16-23P(025)

| Pin | Name | |
|-----|---------|--|
| Α | Temp+ | |
| В | A+ | |
| С | A- | |
| D | NC | |
| Е | HALL U | |
| F | HALL V | |
| G | HALL W | |
| Н | HALL W- | |
| J | NC | |
| K | +5Vdc | |
| L | NC | |
| М | + | |
| | | |

| Pin | Name |
|-----|-----------|
| N | B+ |
| Р | B- |
| R | HALL U- |
| S | HALL V- |
| T | COM/Temp- |
| U | - |
| V | NC |
| W | NC |
| Χ | NC |
| Υ | NC |
| Z | NC |
| | |



5.7.6.3 Brake Connector*

Manufacturer: Amphenol

Amphenol Part No.: PT02E-8-3P(025)


| Pin | Name |
|-----|-------|
| Α | NC |
| В | * BR+ |
| С | * BR- |

Separate Brake connector required Connect brake only when present

NOTE: NC = no connection

Brake Information: 24 Vdc power is required to release the brake during operation. Ensure that pins B and C in the power connector are used for the brake.

5.7.7 Lenze MCS Motor Series - DL1



5.7.7.1 Motor Power Connector - DL1xxx


Manufacturer: Intercontec

Intercontec Part No.: BEDC 106 MR14 00 1216 000

| Pin | Name |
|-----|---------|
| 1 | * BR+ |
| 2 | * BR- |
| 3 | GND** |
| 4 | Phase R |
| 5 | Phase S |
| 6 | Phase T |

*Connect brake only when present

**Required




5.7.7.2 Digital Incremental Encoder Connector - DL1 D1x

Manufacturer: Intercontec

Intercontec Part No.: AEDC 113 MR83 00 1216 000


| Pin | Name |
|------------------|-----------|
| 1 | Temp + |
| 2 3 4 5 | - |
| 3 | + |
| 4 | Temp - |
| | Hall U+ |
| 6 | Hall U- |
| 7 | +5 Vdc |
| 8 | Hall W- |
| 9 | Hall W+ |
| 10 | Com |
| 11 | NC |
| 12 | B+ |
| 13 | B- |
| 14 | Hall V+ |
| 15 | A+ |
| 16 | A- |
| 17 | Hall V- |

Brake Information: 24 Vdc power is required to release the brake during operation. Ensure that pins 1 and 2 in the power connector are used for the brake.



| 5.7.7.3 Resolver Connector - DL1 D1x | | |
|---|------|--|
| Manufacturer: Intercontec | | |
| Intercontec Part No.: AEDC 052 MR83 00 1215 000 | | |
| Din | Nama | |

| Pin | Name |
|-----|--------|
| 1 | Exc |
| 2 | Exc Lo |
| 3 | NC |
| 4 | Cos |
| 5 | Cos Lo |
| 6 | Sin |
| 7 | Sin Lo |
| 8 | NC |
| 9 | NC |
| 10 | NC |
| 11 | Temp + |
| 12 | Temp - |




| 5.7.7. | 4 Multi-turn Absolute | Encoder (| Connec | tor - DL1 A1x |
|------------------|-----------------------|-----------|---------|---------------|
| Manu | facturer: Intercontec | | | |
| Interc | ontec Part No.: AEDC | 052 MR83 | 00 1215 | 5 000 |
| Pin | Name | | Pin | Name |
| 1 | +SIN | | 7 | DATA+ |
| 2 | REFCOS | | 8 | NC |
| 3 | +COS | | 9 | REFSIN |
| 4 | Vcc | | 10 | NC |
| 5 | COM | | 11 | TEMP+ |
| 6 DATA- 12 TEMP- | | | | |
| NOTE: | NC = no connection | 1 | • | • |

Brake Information: 24 Vdc power is required to release the brake during operation. Ensure that pins 1 and 2 in the power connector are used for the brake.

Thermal Device: Motor equipped with a PT1000 temperature sensor.

5.7.8 Siemens 1F Motor Series - DS1




| 5.7.8.1 Motor Power Connector - DS1 xxx |
|---|
| Manufacturer: Intercontec |
| Intercontec Part No.: BEDC 106 MR14 00 1216 000 |

| Pin | Name |
|-----|---------|
| 1 | Phase R |
| 2 | Phase S |
| 3 | GND** |
| 4 | *BR + |
| 5 | *BR – |
| 6 | Phase T |

**Required
*Connect brake only when

present

5.7.8.2 MultiTurn Absolute Encoder Connector - DS1 H1x



| Manufacturer: Intercontec | | |
|--------------------------------|-------------|--|
| Intercontec Part No.: AEDC 113 | | |
| Pin | Name | |
| 1 | A + | |
| 2 | A – | |
| 3 | Data + | |
| 4 | NC | |
| 5 | Clock | |
| 6 | NC | |
| 7 | 0 V (M Enc) | |
| 8 | PT 1000 | |
| 9 | PT 1000 | |

| Pin | Name |
|-----|----------------------|
| 10 | Up (P Enc) |
| 11 | B+ |
| 12 | B- |
| 13 | Data – |
| 14 | Clock – |
| 15 | Sensor 0 V (M Sense) |
| 16 | Sensor Up (P Sense) |
| 17 | NC |

Brake Information: 24 Vdc power is required to release the brake during operation. Ensure that pins 1 and 2 in the power connector are used for the brake.

Thermal Device: Motor equipped with a PT1000 temperature sensor.

△WARNING

Encoder temp is not a way to monitor motor temperature. Performance is based on actuator performance.

△WARNING

In some cases, improper current limits set in the drive, along with incorrect wiring of the feedback cable can lead to damage of the motor.

6: IMA OPERATION AND START UP CONSIDERATIONS

6.1 Attaching Cables & Homing / Mechanical Travel Limits

- 1. Carefully align each cable connector with the respective motor connector.
- 2. Fully seat the feedback and power connectors.
- 3. Verify continuity and functionality of the thermal switch signals, TS+ and TS-. These signals are transmitted through the cables that connects the motor to its motion control system.
- 4. When homing the Tolomatic IMA Actuator avoid excessive force. During homing do not exceed 20% of continuous thrust or speeds of 0.1 in/sec (2.5 mm/sec). Exceeding these recommendations can cause permanent damage to the actuator. Careful attention should always be taken to prevent exceeding the physical limits of the actuator.

A CAUTION

The mechanical travel limits of the actuator must be verified to ensure the actuator will not reach an internal hard limit during normal operation. The end of stroke bumpers should NOT be engaged during normal programmed servo actuator operation.

6.2 Brake

△WARNING

In all vertical application an un-powered Tolomatic IMA Actuator will require a brake to maintain position. Tolomatic recommends that the nominal back drive force specification (listed on page 52) be used for reference only. Back drive force is subject to change throughout the life of the actuator, due to mechanical break in, ambient temperature, and duty cycle variation.

A brake can be used with the actuator to keep it from backdriving, typically in vertical applications. A brake may be used for safety reasons or for energy savings allowing the actuator to hold position when un-powered.



The optional Spring-Applied / Electronically-Released Brake typically requires 24 V power. The brake is spring engaged and electrically released.

A CAUTION

DO NOT attempt to operate the actuator with the brake applied. Allowing the actuator to operate with the brake applied may cause serious damage to the actuator and/or the brake. Do not use the brake to support heavy loads while an operator is under the load. Provide another means to lock the load in position. The brake is a spring applied friction mechanism and does not provide a positive lock.

Protecting the brake from voltage transients in applications where it will be engaged and disengaged frequently is advised. The use of a rectifying diode and zener diode will provide optimal protection against these transients.




Figure 6.1: Fastest Engage / Disengage time, least protection




Figure 6.2: Increased Engage / Disengage time, best protection

7: IMA REPAIR AND MAINTENANCE

△WARNING

Before starting any maintenance activities, make sure that the supply power is shut OFF.

7.1 Lubrication

NEW UNIT: All Tolomatic IMA Actuators have been lubricated at the factory and are ready for installation. If the actuator is placed in storage for more than 1 year after it is received, the actuator should be lubricated through the lubrication port on the thrust rod with Mobilith SHC220 #2744-1016 (QUANTITY: IMA33: 3.0 g; IMA44: 5.0 g; IMA55: 7.0 g and cycled at least two full strokes prior to running in a loaded condition.

Lubrication needs in a given application are dependent on multiple factors:

- Ambient temperature of environment
- Application schedule:
 - Number of extend/retract (long moves) per minute
 - Number of extend/retract (short moves) per minute
 - Actuator thrust rod force required

A CAUTION

Do not over-fill with grease

Overfilling will cause a reduction in performance, excessive heat build up and potential premature failure.

7.2 Periodic Maintenance

PERIODIC MAINTENANCE: In typical applications, it is recommended to re-lubricate the Tolomatic IMA Actuators using the following calculations.

BALL SCREW

Where: $\begin{array}{ll} \hline \text{Where:} \\ \hline \textbf{P}_{IMA} = IMA \text{ Power Output} \\ \hline \textbf{V}_{RMS} = RMS \text{ Velocity } \textit{(in/sec)} \\ \hline \textbf{T}_{RMS} = RMS \text{ Thrust } \textit{(lbf)} \\ \hline \end{array}$

Step 1: Calculate actuator Power Output

$$\mathbf{P}_{\text{IMA}} = \mathbf{V}_{\text{RMS}} \times \mathbf{T}_{\text{RMS}} \times 0.113 \text{ (watts)}$$

Step 2: Select the appropriate actuator power level **Pc**

| | 33 | 44 | 55 |
|---------|-----|-----|-----|
| P_{c} | 105 | 185 | 240 |

Step 3: Calculate the Power Factor

$$\mathbf{K}_{\mathsf{P}} = \frac{\mathbf{P}_{\mathsf{C}}}{\mathbf{P}_{\mathsf{IMA}}}$$

Step 4: The lubrication interval (t_i) for a given cycle is then calculated as:

$$t_{l} = 1,000 (hours) = K_{p} < 1$$

$$t_{l} = 9,000 (hours) = K_{p} < 1$$

- Re-lubricate with Mobilith SHC220 #2744-1016
 (QUANTITY: IMA33: 3.0 g; IMA44: 5.0 g; IMA55: 7.0 g) into the grease zerk located on the rod end.
- IMA22 ball-screw does not require relubrication.

BALL SCREW LUBRICATION (Example Calculation)

Cycle Details:

Product: IMA33 BN V_{RMS}: 1.66 in/sec T_{RMS}: 400 lbf T_{MAX}: 400 lbf

Step 1: Calculate your actuator's power output. **P**_{IMA=} 1.66 in/sec • 400 lbf • 0.113 = 75 (watts)

Step 2: Select the appropriate actuator power level. P_c $P_c = 105 = IMA33BN$

Step 3: Calculate the Power Factor.

$$\mathbf{K}_{p} = \frac{105}{75} = 1.4$$

Step 4: The lubrication interval (t_i) for a given cycle is then calculated as: $t_i = 9000 \; (hours) = K_P > 1$

ROLLER SCREW

For optimal performance and rated life, periodic re-lubrication is required.




Figure 7.1: Roller Screw Lubrication Interval Graph

Where: \mathbf{t}_{BL} = Basic Lubrication Interval (hours) \mathbf{V}_{RMS} = RMS Velocity (in/sec) \mathbf{K}_{T} = Thrust Correction Factor \mathbf{K}_{Co} = Screw Static Load Factor \mathbf{T}_{PEAK} = Actuator Peak Thrust Rating \mathbf{P}_{e} = Cycle Equivalent Load \mathbf{t}_{L} = Lubrication Interval (hours)

Step 1: Select the Basic Lubrication Interval (t_{BL}) based on the cycles RMS Velocity (V_{RMS}). t_{BL} = 4500 x (V_{RMS})-1.57 (hours)

Step 2: Determine the Thrust Correction Factor (K_T) based on the ratio of the Actuator Peak Thrust Rating (T_{PEAK}) to the Cycle Equivalent Load (P_e) .

$$\mathbf{K}_{\mathrm{T}} = \mathbf{K}_{\mathrm{Co}} \left(\frac{\mathsf{T}_{\mathrm{PEAK}}}{\mathsf{P}_{\mathrm{e}}} \right) - 0.15$$

| | 33RN05 | 33RN10 | 44RN05 | 44RN10 | 55RN05 | 55RN10 |
|-----------------|--------|--------|--------|--------|--------|--------|
| K _{Co} | 0.24 | 0.44 | 0.26 | 0.40 | 0.31 | 0.84 |



 $\textbf{Step 3:} \ \ \text{The Lubrication Interval } (\textbf{t}_{L}) \ \text{for a given cycle is then calculated as:}$

 $\mathbf{t}_{L} = \mathbf{t}_{BL} \times \mathbf{K}_{T}$ (hours)

Re-lubricate with Tolomatic Grease #2744-9099 into the grease zerk located on the rod end.

| QUANTIT | QUANTITY | | | | | |
|----------------------------|------------------------|---|--|--|--|--|
| IMA33 | 2.5 + [0.010 x L (mm)] | g | | | | |
| IMA44 | 4.8 + [0.010 x L (mm)] | g | | | | |
| IMA55 | 6.6 + [0.019 x L (mm)] | g | | | | |
| L=stroke length (mm or in) | | | | | | |

| IMA33 | 0.09 + [0.009 x L (in)] | OZ |
|-------|-------------------------|----|
| IMA44 | 0.17 + [0.009 x L (in)] | OZ |
| IMA55 | 0.23 + [0.017 x L (in)] | OZ |
| | | |

ROLLER SCREW LUBRICATION (Example Calculation)

Cycle Details:

Product: IMA33 RN05 V_{RMS}: 1.66 in/sec T_{PEAK}: 1700 lbf P_e: 400 lbf

Step 1: Select the Basic Lubrication Interval (t_{BL}) based on the cycles RMS Velocity (V_{RMS}).

 $t_{BL} = 4500 \text{ x } (1.66 \text{ in/sec})^{-1.57} = 2019 \text{ (hours)}$

Step 2: Determine the Thrust Correction Factor (K_T) based on the ratio of the Actuator Peak Thrust Rating (T_{PEAK}) to the Cycle Equivalent Load (P_e) .

$$\mathbf{K}_{T} = 0.24 \left(\frac{1700 \text{ lbf}}{400 \text{ lbf}} \right) - 0.15 = 0.87$$

| | 33RN05 | 33RN10 | 44RN05 | 44RN10 | 55RN05 | 55RN10 |
|-----------------|--------|--------|--------|--------|--------|--------|
| K _{Co} | 0.24 | 0.44 | 0.26 | 0.40 | 0.31 | 0.84 |



Step 3: The Lubrication Interval (t_L) for a given cycle is then calculated as:

 $t_L = 2019 (hours) \times 0.87 = 1757 (hours)$



Tolomatic recommends validating the output force after 100 000 cycles and on an annual basis thereafter.

It is recommended that the actuator be visually inspected after initial startup and twice a year thereafter, specifically checking for uneven wear or discoloration of the thrust rod which may indicate side loading and lead to premature seal failure. Contact the nearest Tolomatic service center with any concerns or questions.



Figure 7.1: A standard grease zerk allows periodic relubrication for Tolomatic IMA Actuators. This can be done without removing the actuator from its installation.

7.3 Procedure for Jubrication



Before starting any maintenance activities, confirm Tolomatic IMA Actuator is in full retract position and supply power is shut off.

- 1. Ensure Tolomatic IMA Actuator is in full retract position
- 2. Using a standard grease gun, apply the grease (amount determined in previous section) into the grease Zerk on the rod end of the actuator:
- 3. Re-apply power to the Tolomatic IMA Actuator
- 4. Complete five full extend / full retract moves of the Tolomatic IMA Actuator at low speed / low force to properly distribute the grease

A CAUTION

Do not over-fill with grease


Overfilling will cause a reduction in performance, excessive heat build up and potential premature failure.

7.4 Tolomatic IMA Maintenance and Repair

The only user serviceable component of the IMA actuator is the rod wiper.

Further disassembly of the IMA is not recommended. IMA actuators should be returned to Tolomatic for evaluation and repair.

Contact Tolomatic for instructions on how to return the IMA actuator for evaluation.



| Parts Listing | | | | | | | | |
|---------------|-----------|-----------|--|----------------------------|-----------|--|-----------|--|
| Item | Part No. | | Description | | | | | |
| 1. | 2733-9 | 9003 | IMA33 Kit, Bearing / Wiper | | | | | |
| | 2744-9 | 9003 | IMA | IMA44 Kit, Bearing / Wiper | | | | |
| | | IMA33 | | IMA44 | | | | |
| | A. | 2115-103 | 30 | 2744-1003 | Wiper | | | |
| | B. | 1014-103 | 37 | 1019-1037 | O-Ring | | | |
| 1. | 2722-9 | 9146 | IMA22 Kit, Pilot Ring / Wiper | | | | | |
| | 2733-9 | 9146 | IMA33 Kit, Pilot Ring / Wiper | | | | | |
| | 2744-9 | 9146 | IMA44 Kit, Pilot Ring / Wiper | | | | | |
| | 2755-9 | 9146 | IMA55 Kit, Pilot Ring / Wiper | | | | | |
| | | IMA22 | | IMA33 | IMA44 | | IMA55 | |
| | A. | 2552-1 | 132 | 2115-1030 | 2744-1003 | | 2140-1030 | |
| 2. | 0100-1 | 1601 Zerk | | Zerk, Fitting, 1/4-28 | | | | |
| 3. | 2309-1055 | | Set Screw, 1/4-28 (Flush zerk replacement) | | | | | |
| 4. | 2744-1214 | | Grease Fitting Plug, 1/4-28 (leak-proof) | | | | | |
| 5. | 2744-1213 | | Grease Zerk Cap (leak-resistant) | | | | | |

7.5 Wiper Maintenance

In extreme environments it may be necessary to replace the rod bearing/wiper assembly.

IMA33 & 44 manufactured before July 16, 2013

The rod bearing/wiper assembly can be removed, after grease zerk removal, by threading it out of the front plate using a spanner wrench. A new rod bearing/wiper assembly can then be reinstalled. To have this service performed for you, contact Tolomatic.

IMA22, 33, 44 & 55 Manufactured after July 16, 2013

IMA22, 33, 44 and 55 have a replaceable wiper only. The wiper can be replaced by removing the zerk and the screws from the pilot ring.

△WARNING

There is a possibility that base oil may leak from the Grease Zerk (#2). In contamination sensitive applications replace Grease Zerk (#2) with a leak-proof Grease Fitting Plug (#4), or add a leak-resistant Grease Zerk Cap (#5) to cover Grease Zerk (#2).

7.5 Storage Recommendations

Pay attention to the following when storing the actuator:

- Perform repairs, maintenance and inspections before storing equipment to ensure that the equipment is in good working order.
- Ensure that storage will not damage external surface creating pits, scratches or crevices.
- Make sure the equipment is placed in a suitable storage position (horizontal) to prevent damage to the connectors and electronics.
- Protect the feedback device, which is located at the blind (non-rod end) of the Tolomatic IMA Actuator.
- Store in clean and dry environment.
- After six (6) months of storage it is recommended to cycle two complete strokes of the Tolomatic IMA Actuator to redistribute the internal lubricants.
- It is also recommended to cycle the Tolomatic IMA Actuator two complete strokes before placing in service.
- If stored for a period longer than 2 years without use it may be necessary to replace the lubricants. Follow the instructions in section 7.2 or return to Tolomatic for this maintenance.
- Storage temperature is -25°C to +60°C (-13°F to +140°F).

APPENDIX A: SPECIFICATIONS



NOTE Please see Tolomatic <u>IMA Actuator brochure #2700-4000</u> for complete information on performance data. Use 3D CAD files (available at <u>www.tolomatic.com</u>) for critical dimensions.

A.1 Actuator Specifications

Performance and Mechanical Specifications



NOTE Please see Tolomatic <u>IMA Actuator brochure #2700-4000</u> for complete information on performance and mechanical specifications.

A.2 Motor Specifications:



NOTE Please see Tolomatic <u>IMA Actuator brochure #2700-4000</u> for complete information on motor specifications.

A.3 Brake Specifications



NOTE Please see Tolomatic IMA Actuator brochure #2700-4000 for complete information on brake specifications.

A.4 Speed vs Thrust Graphs



NOTE Please see Tolomatic <u>IMA Actuator brochure #2700-4000</u> for complete information on performance data. Refer to the charts for the continuous and peak thrust and speed capabilities of the screw selections.



NOTE: IMA integrated motor rod-style actuators are designed to move guided and supported loads and are not designed for applications that require significant side loading. Please contact Tolomatic at 1-800-328-2174 or 763-478-8000 for details regarding side loading capabilities.

PEAK REGION is the maximum performance capabilities of the actuator system. Higher peak thrusts are achievable by servo motor actuator systems, so please consult Tolomatic before exceeding catalog rating. CONTINUOUS REGION is defined as the RMS thrust and velocity limit that is derived from the thermal limits of the actuator system to achieve the dynamic load rating of the screw. (Example: Extend and retract under force 100% of the time with no dwells.)

$$\begin{aligned} \textbf{T}_{\text{RMS}} &= \sqrt{\frac{\text{sum } (\textbf{T}_{i}^{2} \times \textbf{t}_{i})}{\text{sum } (\textbf{t}_{i})}} \\ \textbf{V}_{\text{RMS}} &= \sqrt{\frac{\text{sum } (\textbf{V}_{i}^{2} \times \textbf{t}_{i})}{\text{sum } (\textbf{t}_{i})}} \end{aligned} \end{aligned}$$
 Where:
$$\begin{aligned} \textbf{T}_{\text{RMS}} &= \text{RMS Thrust} \\ \textbf{V}_{\text{RMS}} &= \text{RMS Velocity} \\ \textbf{T}_{i} &= \text{Thrust during interval i} \\ \textbf{V}_{i} &= \text{Velocity during interval i} \end{aligned}$$

A.5 Calculating RMS Thrust and Velocity for Continuous Duty:

Servo motor actuator systems have two speed / thrust curves: one for continuous (severe duty) and another for peak region (intermittent or operating). The root mean square (RMS) thrust & velocity is based on the application duty cycle and must fall within the continuous duty region of the actuator system. The application maximum thrust

& velocity must fall within the peak region of the actuator system. Higher peak thrusts are achievable by the actuator system, so please consult Tolomatic before exceeding catalog ratings. Use the following formulas when calculating the RMS thrust & velocity. When selecting a servo motor actuator system, it is recommended to add a margin of safety of 15% to the thrust and velocity required to move the load.

A.6 Critical Speed



NOTE Please see Tolomatic <u>IMA Actuator brochure #2700-4000</u> for complete information on motor specifications.

A.7 Ball & Roller Screw Life



NOTE Please see Tolomatic IMA Actuator brochure #2700-4000 for complete information on motor specifications.

A.8 Standard thermal switch specifications

The motor windings have an integral normally closed thermal switch or resistance based temperature measurement device. These devices must be integrated with the robot controller. The switch opens at a temperature of 212° F (100°C), which is the windings maximum operating temperature. The thermal switch is meant to protect the windings, the actuators continuous operating region must still be obeyed. Operation that causes the windings temperature to approach 212° F (100°C) will reduce the expected life of the actuator.

54

APPENDIX B: TROUBLESHOOTING PROCEDURE

| SYMPTOM | POTENTIAL CAUSE | SOLUTION | | |
|--|---|---|--|--|
| No response from | Controller / Drive not enabled | Enable Controller/Drive | | |
| actuator | Controller / Drive faulted | Reset the Controller/Drive | | |
| | Improper / Failed wiring | Check the wiring | | |
| Actuator is enabled but | Feedback cable may be damaged | Test the feedback cable | | |
| is not operating or is operating erratically | Feedback wiring may be incorrect | Verify feedback wiring | | |
| Actuator is operating but is not up to rated | Motor phases are wired incorrectly or in incorrect order | Verify correct wiring of motor armature | | |
| speeds/force | Drive may be improperly tuned | Check all gain settings | | |
| | Drive may be set up improperly for Tolomatic IMA Actuator used | Check drive settings for number of poles, voltage, current, resistance, inductance, inertia, etc. | | |
| | Feedback is improperly aligned | Contact Tolomatic | | |
| Actuator cannot move | Force is too large for the capacity of the actuator or too much friction is present | Verify force requirements | | |
| | Excessive side load | Verify correct operation | | |
| | Misalignment of output rod to application | Verify correct alignment | | |
| | Drive has too low of current capacity or is limited to tool low of current capacity | Verify correct drive and settings | | |
| | Actuator has crashed into hard stop | Disconnect from load and manually move away from hard stop. If problem persists, contact Tolomatic for service. | | |
| Actuator housing moves | • | Check actuator mounting | | |
| or vibrates when shaft is in motion | Drive is improperly tuned – wrong gain settings | Tune drive | | |
| Actuator is overheating | Duty cycle is higher than actuator ratings | Verify duty cycle is within continuous ratings | | |
| | Drive is poorly tuned, causing excessive unnecessary current to be applied to motor | Check gain settings | | |
| | Actuator low or out of grease | Re-lubricate (if applicable) | | |

APPENDIX C: WARRANTY

C.1 Warranty

Warranty and Limitation of Liability

Tolomatic's complete terms and conditions can be found here https://www.tolomatic.com/info-center/resource-details/terms-and-conditions

Limited Warranty

Tolomatic warrants that at the time of delivery, Products shall be in good condition, free from defects in material and workmanship and that Products made to order shall conform to applicable drawings or specifications as referenced in the quotation or accepted purchase order ("Product Warranty"). The Product Warranty shall expire one year from date of shipment (the "Warranty Period"). Tolomatic warrants that Buyer shall acquire good title to the Products free from third party rights. These warranties are given only to Buyer and not to any third party. The Product Warranty excludes any defects or non-conformance resulting (wholly or in part) from: (i) accidental damage, mishandling, incorrect installation, negligence or other circumstances arising after delivery; (ii) the repair or alteration of the Product by any party other than Tolomatic or its authorized representative; (iii) the failure by Buyer to provide a suitable storage, use, or operating environment for the Products; (iv) Buyer's use of the Products for a purpose or in a manner other than that for which they were designed; and (v) other abuse, misuse or neglect of the Products by Buyer or any third party.

The Product Warranty excludes any Products not manufactured by Tolomatic. Insofar as any Products are manufactured by third parties, Tolomatic shall, insofar as it can, pass to the Buyer the benefit of all warranties given by the supplier of such Products.

The Product Warranty shall be limited to defects of which Tolomatic is notified within twenty-one (21) days from the date of shipment to Buyer or, in the event of latent defects, within twenty-one (21) days of the defect being discovered and provided that such notice is received within the Warranty Period. As sole remedy for the breach of the warranty in paragraph (a) above, provided that (if required by Tolomatic) all non-conforming Products are returned to Tolomatic at Buyer's cost, and provided that Tolomatic confirms the defect or non-conformance, Tolomatic shall at its option (i) replace or repair the defective or non-conforming items, or correct any defective work or non-conformance, or (ii) refund to Buyer the original purchase price of the defective or non-conforming item and reimburse to Buyer any transportation and insurance charges incurred by Buyer.

Any claim by Buyer against Tolomatic alleging the breach of the Product Warranty must be commenced within twelve (12) months following the date of the alleged breach.

In the event the parties disagree whether or not a breach of the Product Warranty has occurred, Tolomatic may (but shall not be obliged to) undertake any repairs or replacement requested by Buyer pending final settlement of the matter. If it is determined that no such breach has occurred, Buyer shall pay Tolomatic upon demand the reasonable price of the repairs, corrections, or replacements made by Tolomatic including allowances for overheads and a reasonable profit margin.

THE WARRANTIES EXPRESSLY MADE UNDER THESE TERMS ARE EXCLUSIVE AND GIVEN IN LIEU OF ALL OTHER REPRESENTATIONS, WARRANTIES AND COVENANTS THAT MAY BE IMPLIED BY LAW, BY CUSTOM OF TRADE, BY THESE TERMS, BY THE PURCHASE ORDER OR OTHERWISE WITH RESPECT TO THE PRODUCTS. TO THE FULL EXTENT PERMITTED BY LAW, TOLOMATIC DISCLAIMS AND BUYER WAIVES ALL SUCH REPRESENTATIONS, WARRANTIES AND COVENANTS INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS. BUYER'S SOLE REMEDY FOR BREACH OF WARRANTY IS STATED IN PARAGRAPH (d) ABOVE.

No Products shall be returned without Tolomatic's prior written consent. Products which Tolomatic consents to have returned shall be shipped by Buyer at Buyer's risk and expense, freight prepaid, to such location as Tolomatic designates.

Limitation of Liability

Tolomatic shall in no event be liable to Buyer or any third party, whether in contract, tort (including negligence).

misrepresentation, strict liability or otherwise, for any incidental, punitive, consequential, indirect or special damages, including any loss of profits or savings or anticipated profits or savings, loss of data, loss of opportunity, loss of reputation, loss of goodwill or business or potential business, however caused, even if Tolomatic has been advised of the possibility of such damages in advance.

Under no circumstances shall Tolomatic's liability to Buyer in connection with any purchase order or Products supplied to Buyer exceed an amount equal to the amount paid by Buyer for such Products.

Buyer agrees and understands that it is solely Buyer's responsibility to ensure that Products are suitable for Buyer's requirements and for the environment, facilities or machinery for which they are intended by Buyer or by its end-customer to be fitted or used. Even if Tolomatic is advised of Buyer's intended use, Tolomatic makes no representation or warranty that the Product will be suitable for that purpose. Any technical advice furnished by Tolomatic relating to the intended use of the Products is given for information only and Tolomatic assumes no obligation or liability for the advice given or the results obtained. Except insofar as specifications or drawings form part of a purchase order and the Product Warranty, to the full extent permitted by law, Tolomatic disclaims and Buyer waives all representations, warranties and covenants that may be implied from the provision by Tolomatic of technical advice or information about Product. All such advice and information are accepted by Buyer at its risk. Insofar as any liability or warranty of Tolomatic cannot be limited or excluded under applicable law, including any laws that do not permit limitations on liability relating to death or personal injury, the provisions of these terms and conditions shall be construed as being subject to such legal limitations, but only if those legal provisions have effect in relation to Tolomatic's liability notwithstanding the governing law provision in Section 18

Product Return Procedure

- 1. Before initiating the RMA process and obtaining an RMA number, please contact the Tolomatic Technical Support team to determine if it is possible to correct the issue in the field.
- If an RMA is needed your Tolomatic Technical support team will initiate the RMA process and set up an RMA number. If possible, please contact your local distributor from which the actuator was originally purchased to begin the RMA process.

USA - Headquarters Tolomatic Inc.

3800 County Road 116 Hamel, MN 55340, USA Phone: (763) 478-8000 Toll Free: 1-800-328-2174 sales@folomatic.com www.tolomatic.com

MEXICO Centro de Servicio

Parque Tecnológico Innovación Int. 23, Lateral Estatal 431, Santiago de Ouerétaro, El Marqués, México, C.P. 76246 Phone: +1 (763) 478-8000

help@tolomatic.com

EUROPE Tolomatic Europe GmbH

Hisabethenstr, 20 65428 Rüsselshelm Germany

Phone: +49 6142 17604-0 help@tolomatic.eu

CHINA

Tolomatic Automation Products (Suzhou) Co. Ltd.

No. 60 Chuangye Street, Building 2 Hugiu District, SND Suzhou Jlangsu 215011 P.B. China Phone: +86 (512) 6750-8506 IolomaticChina@folomatic.com

57



EU Declaration of Conformity

No: 36004709_02

We the manufacturer,

Tolomatic 3800 County Road 116 Hamel, MN 55340 USA

declare under our sole responsibility that the product(s),

IMA Actuators

All Models

Fulfills the essential requirements of the following directives:

LVD Directive (2014/35/EU)

EN60034-1 2017 Rotating electrical machines Part 1 Rating and performance

RoHS Directive (2011/65/EU, as amended by (EU) 2015/863)

REACH (Regulation (EC) No 1907/2006)

Assumption of conformity is based on the application of the harmonized or applicable technical standards and, when applicable or required, a European community notified body certification.

Gary Rosengren

Director of Engineering

30.09.2021

Date (dd.mm.yyyy)

© 2022 Tolomatic

Tolomatic. All rights reserved.

Tolomatic and Excellence In Motion are registered trademarks of Tolomatic Incorporated. All other products or brand names are trademarks of their respective holders.

www.tolomatic.com



COMPANY WITH QUALITY SYSTEM CERTIFIED BY DNV GL = ISO 9001 = Certified xile: Hamel, MN

USA - Headquarters

Tolomatic Inc.

3800 County Road 116 Hamel, MN 55340, USA Phone: (763) 478-8000 Tell Free: 1-800-328-2174 sales@folomatic.com www.tolomatic.com

MEXICO

Centro de Servicio

Parque Tecnológico Innovación Int. 23, Lateral Estatal 431, Santiago de Ouerélaro, El Marqués, México, C.P. 76246 Phone: ⊤1 (763) 478-8000 help@folomatic.com

EURÓPE

Tolomatic Europe GmbH Hisabethenstr. 20 65428 Rüsselshelm

Germany Phone: +49 6142 17604-0 help@tolomatic.eu

CHINA

Tolomatic Automation Products (Suzhou) Co. Ltd.

No. 60 Chuangye Street, Building 2 Huqiu District, SND Suzhou Jlangsu 215011 P.B. China Phone: +86 (512) 6750-8506 TolomaticChina@folomatic.com

All brand and product manca are trademarks or registered trademarks of their respective owners, information in this document is believed accurate at time of printing. However, followable assumes no responsibility for its use or for any errors.

that may appear in this document. Tolomatic reserves the right to change the design or operation of the equipment described herein and any associated metion products without notice. Information in this document is subject to change without notice.

Visit www.tolomatic.com for the most up-to-date technical information