

2171-4003 05


RSX080 Extreme Force Electric Linear Actuator

80mm Series


Tolomatic recommends returning the RSX for most repairs. There are a few procedures that can be done in the field. See the following instructions:

RSX Seal Cartridge Replacement

- 1. Lock out/Tag out and safely secure the actuator
- 2. Retract the Thrust Tube if possible
- 3. Remove tooling from the Rod End of the actuator
- 4. Remove Front Flange mount if equipped




- 5. Remove any debris from around the Seal Cartridge
- 6. Remove the six Cartridge Retainer Bolts and Sealing Washers from the Seal Cartridge
- 7. Slide the old Seal Cartridge off the Thrust Tube
- 8. Install new O-Ring on new Seal Cartridge
- 9. Carefully slide the new Seal Cartridge onto the Thrust Tube and align to the bolt holes in the Head
- 10. Carefully install new Sealing Washers on the new Cartridge Retainer Bolts
- 11. Apply Loctite 242 to Cartridge Retainer Bolts and install into new Seal Cartridge



- 12. Torque Cartridge Retainer Bolts to 50 in-lbf (6 N-m)
- 13. Reinstall the Front Flange if applicable
 - a. Apply Loctite 271 to the tie rod threads
 - b. RSX080, torque to 50 ft-lbf (68 N-m)

RSX Relubrication

1. Remove the Lube Access Cover from the Cylinder Body



- 2. Extend or retract the Thrust Tube so that the Grease Zerk on the Nut Assembly is accessible through the access port
- 3. Pump grease into the Grease Zerk See instructions on next page for lubrication interval and quantity
 - Standard grease type is Mobilith 220 unless otherwise specified
- 4. Fully extend and retract the Thrust Tube to distribute the grease
- 5. Verify the O-Ring is in place then reinstall the Tube Access Cover onto the Cylinder Body

(Continues)

RE-LUBRICATION RECOMMENDATION:

Lubrication requirements for electric actuators depend on the motion cycle (velocity, force, duty cycle), type of application, ambient temperature, environmental surrounding and various other factors.


For many general purpose applications, Tolomatic ball screw actuators are typically considered lubricated for life unless otherwise specified, such as those actuator models outfitted with a re-lubrication feature. For roller screw or ball screw actuators outfitted with a re-lubrication feature, Tolomatic recommends to re-lubricate the actuator at least once per year or every 1,000,000 cycles, whichever comes first, to maximize service life. For more demanding applications such as

pressing, high frequency or other highly stressed applications, the re-lubrication interval for these actuators will vary and will need to be more frequent. In these demanding applications, it is recommended to execute at least 5 full stroke moves every 5,000 cycles of operation (or more frequent if possible) to re-distribute the grease within the actuator.

Re-lubricate with Tolomatic Grease into the grease port located on the side of the actuator.

	RSX080
Quantity (g)	8.0 + (0.020 x Stroke ^{mm})
Quantity (oz)	0.28 + (0.018 x Stroke ⁱⁿ)


Stroke^{mm} = Stroke length in millimeters Strokeⁱⁿ = Stroke length in inches



RSX RP Parts List



See Tolomatic document 3600-4212 for RP motor assembly and belt tension procedure




RSX RP Parts List

			QUANTITY	
ITEM	PART NO	DESCRIPTION	RP1	RP2
1	4410-1026	Dowel Pin	2	2
2	*	RP Plate	1	1
3	2170-1088	Socket Head Cap Screw	8	8
4	2170-1103	Key	1	1
5	1164-1597	Set Screw	2	2
6	2170-1026	Actuator Pulley RP1	1	_
0	2170-1025	Actuator Pulley RP2	_	1
7	2133-1017	Spacer	1	1
8	2133-1065	Lock Washer	1	1

			QUANTITY	
ITEM	PART NO	DESCRIPTION	RP1	RP2
9	2133-1064	Lock Nut	1	1
10	2170-1087	Socket Head Cap Screw	6	6
11	2170-1046	RP Cover	1	1
12	*	Motor Pulley	1	1
13	8350-1008	Set Screw	4	4
14	2170-1069	Belt	1	1

*YMH Variable Parts





ITEM or Code	PART NO	DESCRIPTION	ОТУ
PCD	2170-9019	Clevis Mount Kit	Q
1	2170-1084	Bracket	2
2	2170-1091	Pin	1
3	2170-1093	Retaining Ring	2
4	2170-1101	Socket Head Cap Screw	4
5	2170-1090	Plate	1
6	2170-1112	Flat Head Cap Screw	4
TRR	2170-1085	Trunnion Mount Option	
7	2170-1085	Trunnion Plate	1
MP2	2170-9017	Mounting Plate Kit	
8	2170-1110	Dowel Pin	4
9	2170-1109	Bracket	2
10	2170-1088	Socket Head Cap Screw	4
XT	*	Extended Tie Rod Kit	
12	*	Tie Rod	4
13	2170-1142	Washer	4
14	2170-1047	Hex Nut	4
FFG	2170-1062	Front Flange Option	
15	2170-1062	Flange Plate	1
CLV	2170-9013	Rod End Clevis Kit	
16	2170-1114	Hex Nut	1
17	2170-1113	Clevis	1


IIEW	Contig. Code	DESCRIPTION
SWITCHES WITH QUICK-DISCONNECT COUPLERS		
	SWRSX080RK	Reed Switch, SPST Normally Open
	SWRSX080NK	Reed Switch, SPST Normally Closed
	SWRSX080TK	Solid State Switch, PNP (Sourcing)
		Normally Open
18	CINDCAUGURIA	Solid State Switch, NPN (Sinking)
10	SWRSX080KK	Normally Open
	SWRSX080PK	Solid State Switch, PNP (Sourcing)
		Normally Closed
	CMDCAOOUIK	Solid State Switch, NPN (Sinking)
	SWRSX080HK	Normally Closed
NOTE	: Includes retaine	ed hardware & female connector for
quick-	disconnect	
SWI	TCHES WITHOUT	QUICK-DISCONNECT COUPLERS
	SWRSX080RY	Reed Switch, SPST Normally Open
	SWRSX080NY	Reed Switch, SPST Normally Closed
	SWRSX080TY	Solid State Switch, PNP (Sourcing)
	SWHSXUOUTT	Normally Open
19	SWRSX080KY	Solid State Switch, NPN (Sinking)
19		Normally Open
	SWRSX080PY	Solid State Switch, PNP (Sourcing)
		Normally Closed
	SWRSX080HY	Solid State Switch, NPN (Sinking)
		Normally Closed


*Variable Parts


SWITCH WIRING DIAGRAMS AND LABEL COLOR CODING (CE and RoHS Compliant)





















SWITCH DETECTION POINT



SWITCH INSTALLATION



Place switch bracket onto any one of the four tie rods that run the length of the extruded tube. Insert the switch with set screw and the word "Tolomatic" facing up and slide it the mating slot on the bracket. Position the bracket with the switch to the exact location desired, with the bracket tight to the surface of the extrusion, then lock the bracket securely into place by tightening the set screw with the Allen wrench provided. Then tighten the switch into the bracket with a small slotted screwdriver.





COMPANY WITH
QUALITY SYSTEM
CERTIFIED BY DNV GL
= ISO 9001=

3800 County Road 116, Hamel, MN 55340 USA https://www.tolomatic.com • Email: Help@Tolomatic.com Phone: (763) 478-8000 • Fax: (763) 478-8080 • Toll Free: 1-800-328-2174

marks of their respective owners. Information in this document is believed accurate at time of printing. However, Tolomatic assumes on responsibility for its use or for any errors that may appear in this document. Tolomatic reserves the right to change the design or operation of the equipment described herein and any associated motion products without notice. Information in this document is subject to change without notice.

All brand and product names are trademarks or registered trade-